


# Service Service Service



21A582BH/00C



DDC/Audio/Power saving/Tilt correction

# Service Manual

Horizontal frequencies  
30 - 115 kHz

## TABLE OF CONTENTS

Description	Page	Description	Page
<b>PART-I : Technical data</b>		U-CTRL (B3) Schematic Diagram-----	22
Important Safety Notice -----	2	Power Supply (C) Schematic Diagram-----	23
Hex Data of DDC1/2B-----	3~6	Main Panel (B1, B2, B3, C & D) C.B.A.-----	24
Warning and Notes -----	7	USB (D) Schematic Diagram-----	25
Electrical Adjustments -----	8,9	Key controlpanel and Power Switch (E)-----	26
USB Connections-----	10	Repair Tips-----	27
Quick Reference for OSD Adjustment-----	11~14	Exploded View -----	28
Mechanical Adjustments and Wiring diagram ----	15	Spare parts list-----	29~32
Block Diagram -----	16	CM5800 BRIEF -----	33~36
Video (A), Power Switch (G), Earphone (F) & Terminal Panel (A1) C.B.A.-----	17		
Terminal Panel (A1) Schematic Diagram -----	18	<b>PART-II: Directions For Use</b>	
Video Panel (A2) Schematic Diagram -----	19		
Main Panel (B1) Schematic Diagram-----	20		
Main Panel (B2) Schematic Diagram-----	21		

REFER TO BACK COVER FOR IMPORTANT SAFETY GUIDELINES

## SAFETY NOTICE

ANY PERSON ATTEMPTING TO SERVICE THIS CHASSIS MUST FAMILIARIZE HIMSELF WITH THE CHASSIS AND BE AWARE OF THE NECESSARY SAFETY PRECAUTIONS TO BE USED WHEN SERVICING ELECTRONIC EQUIPMENT CONTAINING HIGH VOLTAGES.

**CAUTION: USE A SEPARATE ISOLATION TRANSFORMER FOR THIS UNIT WHEN SERVICING.**



# PHILIPS

## IMPORTANT SAFETY NOTICE

Proper service and repair is important to the safe, reliable operation of all Philips Consumer Electronics Company\*\* Equipment. The service procedures recommended by Philips and described in this service manual are effective methods of performing service operations. Some of these service operations require the use of tools specially designed for the purpose. The special tools should be used when and as recommended.

It is important to note that this manual contains various CAUTIONS and NOTICES which should be carefully read in order to minimize the risk of personal injury to service personnel. The possibility exists that improper service methods may damage the equipment. It also is important to understand that these CAUTIONS and NOTICES ARE NOT EXHAUSTIVE. Philips could not possibly know, evaluate and advise the service trade of all conceivable ways in which service might be done or of the possible hazardous consequences of each way. Consequently, Philips has not undertaken any such broad evaluation. Accordingly, a servicer who uses a service procedure or tool which is not recommended by Philips must first satisfy himself thoroughly that neither his safety nor the safe operation of the equipment will be jeopardized by the service method selected.

\*\* Hereafter throughout this manual, Philips Consumer Electronics Company will be referred to as Philips.

### WARNING

Critical components having special safety characteristics are identified with a  by the Ref. No. in the parts list and enclosed within a broken line\* (where several critical components are grouped in one area) along with the safety symbol  on the schematics or exploded views.

Use of substitute replacement parts which do not have the same specified safety characteristics may create shock, fire, or other hazards.

Under no circumstances should the original design be modified or altered without written permission from Philips. Philips assumes no liability, express or implied, arising out of any unauthorized modification of design. Servicer assumes all liability.

\* Broken Line 

FOR PRODUCTS CONTAINING LASER :

DANGER- Invisible laser radiation when open. AVOID DIRECT EXPOSURE TO BEAM.

CAUTION- Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

CAUTION- The use of optical instruments with this product will increase eye hazard.

**TO ENSURE THE CONTINUED RELIABILITY OF THIS PRODUCT, USE ONLY ORIGINAL MANUFACTURER'S REPLACEMENT PARTS, WHICH ARE LISTED WITH THEIR PART NUMBERS IN THE PARTS LIST SECTION OF THIS SERVICE MANUAL.**

***** ty107a.chk *****		Normal Display, No stereo Digital Separate Sync Positive V Sync Negative H Sync	
Vendor/Product Identification		Detailed Timing #2	
ID Manufacturer Name	: PHL	Pixel Clock (MHz)	: 108.000
ID Product Code	: 1021	H Active (pixels)	: 1152
ID Serial Number	: 123456	H Blanking (pixels)	: 352
Week of Manufacture	: 49	V Active (lines)	: 900
Year of Manufacture	: 1997	V Blanking (lines)	: 43
EDID Version, Revision		H Sync Offset (F Porch) (pixels)	: 16
Version	: 1	H Sync Pulse Width (pixels)	: 64
Revision	: 1	V Sync Offset (F Porch) (lines)	: 2
Basic Display Parameters/Features		V Sync Pulse Width (lines)	: 8
Video Input Definition	: Analog Video Input	H Image Size (mm)	: 380
	0.700V/0.300V (1.00Vpp)	V Image Size (mm)	: 285
	without Blank-to-Black Setup	H Border (pixels)	: 0
	Separate Sync	V Border (lines)	: 0
	Composite Sync	Flags	: Non-interlaced
	Sync on Green		Normal Display, No stereo
	no Serration required		Digital Separate Sync
Maximum H Image Size	: 38 cm		Positive V Sync
Maximum V Image Size	: 29 cm		Positive H Sync
Display Transfer Characteristic:	2.800	Detailed Timing #3	
(gamma)		Pixel Clock (MHz)	: 229.500
Feature Support (DPMS)	: Standby	H Active (pixels)	: 1600
	Suspend	H Blanking (pixels)	: 560
	Active Off	V Active (lines)	: 1200
	RGB color display	V Blanking (lines)	: 50
Color Characteristics		H Sync Offset (F Porch) (pixels)	: 64
Red X coordinate	: 0.625	H Sync Pulse Width (pixels)	: 192
Red Y coordinate	: 0.340	V Sync Offset (F Porch) (lines)	: 1
Green X coordinate	: 0.285	V Sync Pulse Width (lines)	: 3
Green Y coordinate	: 0.605	H Image Size (mm)	: 380
Blue X coordinate	: 0.150	V Image Size (mm)	: 285
Blue Y coordinate	: 0.065	H Border (pixels)	: 0
White X coordinate	: 0.281	V Border (lines)	: 0
White Y coordinate	: 0.311	Flags	: Non-interlaced
Established Timings			Normal Display, No stereo
Established Timings I	: 640 x 480 @60Hz (VGA,IBM)		Digital Separate Sync
	640 x 480 @75Hz (VESA)		Positive V Sync
Established timings II	: 800 x 600 @75Hz (VESA)		Positive H Sync
	1024 x 768 @75Hz (VESA)	Detailed Timing #4	
	1280 x 1024 @75Hz (VESA)	Pixel Clock (MHz)	: 256.140
Manufacturer's timings	: 1152 x 870 @75Hz	H Active (pixels)	: 1800
(MacII,Apple)		H Blanking (pixels)	: 629
Standard Timing Identification #1		V Active (lines)	: 1350
Horizontal active pixels	: 800	V Blanking (lines)	: 56
Aspect Ratio	: 4:3	H Sync Offset (F Porch) (pixels)	: 133
Refresh Rate	: 85	H Sync Pulse Width (pixels)	: 192
Standard Timing Identification #2		V Sync Offset (F Porch) (lines)	: 7
Horizontal active pixels	: 1024	V Sync Pulse Width (lines)	: 3
Aspect Ratio	: 4:3	H Image Size (mm)	: 380
Refresh Rate	: 85	V Image Size (mm)	: 285
Standard Timing Identification #3		H Border (pixels)	: 0
Horizontal active pixels	: 1280	V Border (lines)	: 0
Aspect Ratio	: 5:4	Flags	: Non-interlaced
Refresh Rate	: 85		Normal Display, No stereo
Detailed Timing #1			Digital Separate Sync
Pixel Clock (MHz)	: 25.170		Positive V Sync
H Active (pixels)	: 640		Positive H Sync
H Blanking (pixels)	: 160	Extension Flag	
V Active (lines)	: 400		: 0
V Blanking (lines)	: 49	Check sum	
H Sync Offset (F Porch) (pixels)	: 16		: 74(1ex)
H Sync Pulse Width (pixels)	: 96		
V Sync Offset (F Porch) (lines)	: 12		
V Sync Pulse Width (lines)	: 2		
H Image Size (mm)	: 380		
V Image Size (mm)	: 285		
H Border (pixels)	: 8		
V Border (lines)	: 7		
Flags	: Non-interlaced		
	Normal Display, No stereo		

## Hex Data of DDC1/2B(107k)

## For Hitachi CRT

0: 0	1: ff	2: ff	3: ff	4: ff	5: ff	6: ff	7: 0
8: 41	9: c	10: 21	11: 10	12: 40	13: e2	14: 1	15: 0
16: 31	17: 7	18: 1	19: 1	20: e	21: 26	22: 1d	23: b4
24: e8	25: 0	26: b2	27: a0	28: 57	29: 49	30: 9b	31: 26
32: 10	33: 48	34: 4f	35: 24	36: 43	37: 80	38: 45	39: 59
40: 61	41: 59	42: 81	43: 99	44: 1	45: 1	46: 1	47: 1
48: 1	49: 1	50: 1	51: 1	52: 1	53: 1	54: d5	55: 9
56: 80	57: a0	58: 20	59: 90	60: 31	61: 10	62: 10	63: 60
64: c2	65: 0	66: 7c	67: 1d	68: 11	69: 8	70: 7	71: 1c
72: 30	73: 2a	74: 80	75: 60	76: 41	77: 84	78: 2b	79: 30
80: 10	81: 40	82: 28	83: 0	84: 7c	85: 1d	86: 11	87: 0
88: 0	89: 1e	90: a6	91: 59	92: 40	93: 30	94: 62	95: b0
96: 32	97: 40	98: 40	99: c0	100: 13	101: 0	102: 7c	103: 1d
104: 11	105: 0	106: 0	107: 1e	108: e	109: 64	110: 8	111: 75
112: 72	113: 46	114: 38	115: 50	116: 85	117: c0	118: 73	119: 0
120: 7c	121: 1d	122: 11	123: 0	124: 0	125: 1e	126: 0	127: 74



\*\*\*\*\*  
 ty115new.chk  
 \*\*\*\*\*

## Vendor/Product Identification

ID Manufacturer Name : PHL  
 ID Product Code : 1121  
 ID Serial Number : 123456  
 Week of Manufacture : 49  
 Year of Manufacture : 1997

## EDID Version, Revision

Version : 1  
 Revision : 1

## Basic Display Parameters/Features

Video Input Definition : Analog Video Input  
 0.700V/0.300V (1.00Vpp)  
 without Blank-to-Black Setup  
 Separate Sync  
 Composite Sync  
 Sync on Green  
 no Serration required  
 Maximum H Image Size : 38 cm  
 Maximum V Image Size : 29 cm  
 Display Transfer Characteristic: 2.800  
 (gamma)  
 Feature Support (DPMS) : Standby  
 Suspend  
 Active Off  
 RGB color display

## Color Characteristics

Red X coordinate : 0.625  
 Red Y coordinate : 0.340  
 Green X coordinate : 0.285  
 Green Y coordinate : 0.605  
 Blue X coordinate : 0.150  
 Blue Y coordinate : 0.065  
 White X coordinate : 0.281  
 White Y coordinate : 0.311

## Established Timings

Established Timings I : 640 x 480 @60Hz (VGA,IBM)  
 640 x 480 @75Hz (VESA)  
 Established timings II : 800 x 600 @75Hz (VESA)  
 1024 x 768 @75Hz (VESA)  
 1280 x 1024 @75Hz (VESA)  
 Manufacturer's timings : 1152 x 870 @75Hz (MacII,Apple)

## Standard Timing Identification #1

Horizontal active pixels : 800  
 Aspect Ratio : 4:3  
 Refresh Rate : 85

## Standard Timing Identification #2

Horizontal active pixels : 1024  
 Aspect Ratio : 4:3  
 Refresh Rate : 85

## Standard Timing Identification #3

Horizontal active pixels : 1280  
 Aspect Ratio : 5:4  
 Refresh Rate : 85

## Standard Timing Identification #4

Horizontal active pixels : 1600  
 Aspect Ratio : 4:3  
 Refresh Rate : 85

## Detailed Timing #1

Pixel Clock (MHz) : 25.170  
 H Active (pixels) : 640  
 H Blanking (pixels) : 160  
 V Active (lines) : 400  
 V Blanking (lines) : 49  
 H Sync Offset (F Porch) (pixels): 16  
 H Sync Pulse Width (pixels) : 96  
 V Sync Offset (F Porch) (lines): 12

V Sync Offset (F Porch) (lines): 12

V Sync Pulse Width (lines) : 2

H Image Size (mm) : 380

V Image Size (mm) : 285

H Border (pixels) : 8

V Border (lines) : 7

Flags : Non-interlaced  
 Normal Display, No stereo  
 Digital Separate Sync  
 Positive V Sync  
 Negative H Sync

## Detailed Timing #2

Pixel Clock (MHz) : 108.000

H Active (pixels) : 1152

H Blanking (pixels) : 352

V Active (lines) : 900

V Blanking (lines) : 43

H Sync Offset (F Porch) (pixels): 16

H Sync Pulse Width (pixels) : 64

V Sync Offset (F Porch) (lines): 2

V Sync Pulse Width (lines) : 8

H Image Size (mm) : 380

V Image Size (mm) : 285

H Border (pixels) : 0

V Border (lines) : 0

Flags : Non-interlaced  
 Normal Display, No stereo  
 Digital Separate Sync  
 Positive V Sync  
 Positive H Sync

## Detailed Timing #3

Pixel Clock (MHz) : 243.230

H Active (pixels) : 1600

H Blanking (pixels) : 562

V Active (lines) : 1200

V Blanking (lines) : 50

H Sync Offset (F Porch) (pixels): 66

H Sync Pulse Width (pixels) : 192

V Sync Offset (F Porch) (lines): 1

V Sync Pulse Width (lines) : 3

H Image Size (mm) : 380

V Image Size (mm) : 285

H Border (pixels) : 0

V Border (lines) : 0

Flags : Non-interlaced  
 Normal Display, No stereo  
 Digital Separate Sync  
 Positive V Sync  
 Positive H Sync

## Detailed Timing #4

Pixel Clock (MHz) : 256.140

H Active (pixels) : 1800

H Blanking (pixels) : 629

V Active (lines) : 1350

V Blanking (lines) : 56

H Sync Offset (F Porch) (pixels): 133

H Sync Pulse Width (pixels) : 192

V Sync Offset (F Porch) (lines): 7

V Sync Pulse Width (lines) : 3

H Image Size (mm) : 380

V Image Size (mm) : 285

H Border (pixels) : 0

V Border (lines) : 0

Flags : Non-interlaced  
 Normal Display, No stereo  
 Digital Separate Sync  
 Positive V Sync  
 Positive H Sync

Extension Flag

0

Check sum

c(115k)

## Hex Data of DDC1/2B (FOR 115K)

For Hitachi CRT

0: 0	1: ff	2: ff	3: ff	4: ff	5: ff	6: ff	7: 0
8: 41	9: c	10: 21	11: 11	12: 40	13: e2	14: 1	15: 0
16: 31	17: 7	18: 1	19: 1	20: e	21: 26	22: 1d	23: b4
24: e8	25: 0	26: b2	27: a0	28: 57	29: 49	30: 9b	31: 26
32: 10	33: 48	34: 4f	35: 24	36: 43	37: 80	38: 45	39: 59
40: 61	41: 59	42: 81	43: 99	44: a9	45: 59	46: 1	47: 1
48: 1	49: 1	50: 1	51: 1	52: 1	53: 1	54: d5	55: 9
56: 80	57: a0	58: 20	59: 90	60: 31	61: 10	62: 10	63: 60
64: c2	65: 0	66: 7c	67: 1d	68: 11	69: 8	70: 7	71: 1c
72: 30	73: 2a	74: 80	75: 60	76: 41	77: 84	78: 2b	79: 30
80: 10	81: 40	82: 28	83: 0	84: 7c	85: 1d	86: 11	87: 0
88: 0	89: 1e	90: 3	91: 5f	92: 40	93: 32	94: 62	95: b0
96: 32	97: 40	98: 42	99: c0	100: 13	101: 0	102: 7c	103: 1d
104: 11	105: 0	106: 0	107: 1e	108: e	109: 64	110: 8	111: 75
112: 72	113: 46	114: 38	115: 50	116: 85	117: c0	118: 73	119: 0
120: 7c	121: 1d	122: 11	123: 0	124: 0	125: 1e	126: 0	127: c

## Warnings

1. Safety regulations require that the unit should be returned in its original condition and that components identical to the original components are used. The safety components are indicated by the symbol **▲**.
2. In order to prevent damage to ICs and transistors, all high-voltage flash-overs must be avoided. In order to prevent damage to the picture tube, the method shown in Fig. 1 should be used to discharge the picture tube. Use a high-voltage probe and a multimeter (position DC-V). Discharge until the meter reading is **0 V** (after approximately 30 seconds).
3. **ESD** **▲**  
All ICs and many other semiconductors are sensitive to electrostatic discharges (ESD). Careless handling during repair can drastically shorten their life. Make sure that during repair you are connected by a pulse band with resistance to the same potential as the ground of the unit. Keep components and tools also at this same potential.
4. When repairing a unit, always connect it to the AC Power voltage via an isolating transformer.
5. Be careful when taking measurements in the high-voltage section and on the picture tube panel.
6. It is recommended that safety goggles be worn when replacing the picture tube.
7. When making adjustments, use plastic rather than metal tools. This will prevent any short-circuit or the danger of a circuit becoming unstable.
8. Never replace modules or other components while the unit is switched on.
9. Together with the deflection unit, the picture tube is used as an integrated unit. Adjustment of this unit during repair is not recommended.
10. After repair, the wiring should be fastened in place with the cable clamps.

## Notes

1. The direct voltages and waveforms are average voltages. They have been measured using the Service test software and under the following conditions :
  - Mode : 1024 \* 768 (56.5kHz / 70Hz)
  - Signal pattern : grey scale
  - Adjust brightness and contrast control for the mechanical mid-position (click position)
2. The picture tube panel has printed spark gaps. Each spark gap is connected between an electrode of the picture tube and the Aquadag coating.
3. The semiconductors indicated in the circuit diagram(s) and in the parts lists are completely interchangeable per position with the semiconductors in the unit, irrespective of the type indication on these semiconductors.




Fig.1

# Electrical Adjustments

## 0. General

When carry-out the electrical settings in many cases a video signal must be applied to the monitor. A computer with :

- ATI GPT-1600 (4822 397 10065), Mach 64 (up to 115kHz)

are used as the video signal source. The signal patterns are selected from the "service test software" package, see user guide 4822 727 21046 (GPT-1600).

0.1 This monitor has 14 factory-preset modes as below.

640 x 400 31.5 kHz/70 Hz	1152 x 870 68.7 kHz/75 Hz
640 x 480 31.5 kHz/60 Hz	1152 x 900 71.8kHz/76Hz
640 x 480 37.5 kHz/75 Hz	1280 x 1024 80.0 kHz/75 Hz
800 x 600 46.9 KHz/75Hz	1280 x 1024 91.1 kHz/85Hz
800 x 600 53.7 kHz/85Hz	1600 x 1200 106.25 kHz/85 Hz
1024 x 768 60.0 kHz/75 Hz	1800 x 1350 105.45kHz/75Hz
1024 x 768 68.7 kHz/85 Hz	1600 x 1200 112.5kHz/90Hz

0.2 With normal VGA card:

If not using the ATI card during repair or alignment, The service engineer also can use this service test software adapting with normal standard VGA adaptor and using standard VGA mode 640 x 480, 31.5 kHz/60 Hz (only) as signal source.

0.3 AC/DC Measurement:

The measurements for AC waveform and DC figure is based on 640 x 480 31.5 kHz/60 Hz resolution mode with test pattern "gray scale".  
Power input: 110V AC

## 1. B+ supply voltage (3194) 210Vdc

- Apply a video signal in the 1024 x 768 with 69 kHz/85Hz mode.
- Select the "cross-hatch" pattern.
- Set the brightness control and the contrast control to the minimum position.
- Pre-set trimming potentiometer 3194(+) and 3644(EHT) in mid-position.
- Set Vg2 (screen) to fully Counter-clockwise (zero beamcurrent).
- Connect a dc voltmeter between the joint of capacitor 2181 and ground (common ground).
- Set the B+ trimming potentiometer 3194 so that the reading on the dc voltmeter is 210 V +/- 0.5 Vdc.

## 2. High-voltage EHT (3644)

- Apply a video signal in the 1024 \* 768 with 69 kHz/85Hz mode.
- Select the "cross-hatch" pattern.
- Set the brightness control and the contrast control to the minimum position.
- Turn off the power.
- Connect a "high-voltage voltmeter" between the high-voltage connection of the picture tube and earth.
- Turn on the power.
- Set the EHT trimming potentiometer 3644 so that the "high-voltage voltmeter" reads 26.8 kV +/- 0.2 kV (for 21").

- Turn off the power.
- Remove the "high-voltage voltmeter" from the picture tube.
- Turn on the power again.
- Remove the "high-voltage voltmeter" from the picture tube.
- Turn on the power again.

## 3. Monitor the following auxiliary voltages.

- + 12.0V SOURCE ACROSS C2192 + 12.0V +/- 0.5VDC.
- + 15.0V SOURCE ACROSS C2187 + 15.0V +/- 1.0VDC.
- 15.0V SOURCE ACROSS C2189 - 15.0 V +/- 1.0VDC.
- + 6.3 V SOURCE ACROSS D6195 "-" 6.3V +/- 0.5VDC.
- +145.0V SOURCE ACROSS C2182 +145.0V +/- 2.0VDC.
- +210.0V SOURCE ACROSS C2181 + 210.0V +/- 1.5VDC.
- + 81.0V SOURCE ACROSS C2185 + 81.0 V +/- 2.0VDC.

## 4. General conditions for alignment

- 4.1 During all alignments, supply a distortion free AC mains voltage to set via an isolating transformer with low internal impedance.
- 4.2 Align in pre-warmed condition, at least 30 minutes warm-up with nominal picture brightness.
- 4.3 Purity, geometry and subsequent alignments should be carried out in with correct magnetic field.


Northern hemisphere : H=0, V=430 mG, Z=0

Southern hemisphere : H=0, V=-520 mG, Z=0

Equatorial Support : H=0, V=0 mG, Z=0







- 4.4 All voltages are to be measured or applied with respect to ground.

**Note: Do not use heatsink as ground.**

- 4.5 Adjust function controls "  " to center position except for contrast control which should be set to MAX.
- 4.6 Apply a video signal in the 1024 x 768 with 69kHz/85Hz mode, select cross hatch pattern, set the Brightness for visible raster, adjust H-size for 380mm (21" monitor)

"raster width", adjust R3551 for Horizontal raster center.

## 5. To access factory mode:


- Turn off monitor (don't turn off PC)
  - Press "  " and "  " simultaneously on the front control panel, until the OSD menu with characters " factory mode (below OSD menu)" come on the screen of monitor.
  - Highlighting on factory mode, then enter, that aglintou display on screen, 2nd procedure must carried out from aglintou to aglintof.
  - If OSD menu disappears on the screen of monitor, press "  " again (anytime), then the OSD menu comes on the screen again.
  - using "  " : to select OSD menu.
  - using "  " : to increase or decrease the setting.
- (Please also refer to page 4,5,6 and 7 for OSD adjustment)
- Using "  " to confirm the selection.




## 5.1. To leave factory mode

\* After alignment of factory mode, Select EXIT mode then turn off monitor (if you do not select EXIT mode then turn off monitor, the OSD menu is always at the factory mode), then turn on monitor again (at this moment, the OSD menu is always at factory mode).

## 6. OSD CONTROLS (During alignment)

During alignment, please use the "OSD controls" to keep OSD menu, or to shift OSD menu as below.



-  **TIMER** Set OSD display time, select "OFF", then the OSD menu will stay on the screen (won't disappear).
-  **VERTICAL POSITION** Move the OSD windows up or down.
-  **HORIZONTAL POSITION** Move the OSD window left or right.

## 7. Alignment of Vg2 cut-off point, white tracking (OSD control)

Equipment : 1. Video Test Generator-801GC (Quantum Data)  
2. Color-analyzer (Minolta CA-100)

VG2 [(screen), at the bottom of the L.O.T.].

- \* Apply a video signal in the 1024 x 768 with 69 kHz/85 Hz mode, select the "full white pattern".
- \* Use color-analyzer (Minolta CA-100) to adjust cutoff and white uniformity.

OSD R/G/B cut-off and R/G/B gain can be accessed, with initial data:

R cutoff = 30%, R gain = 70%  
G cutoff = 30%, G gain = 70%  
B cutoff = 30%, B gain = 70%

Step 1: To select the character "FACTORY MODE" as shown in Fig. 2.1, press " " to access the OSD menu for R/G/B gain & cutoff as shown in Fig. 2.2.

Step 2: Use " " to increase or decrease the value as shown in Fig. 2.3.




Fig. 2.2  
FACTORY MODE

	GAIN	CUTOFF
9300K	R G B	R G B SUB
6500K	R G B	R G B SUB
5500K	R G B	R G B SUB
FULL-SIZE :	H V	
LINEARITY :	H V V-BAL	
EXIT ALIGNTOF		

FACTORY MODE

	GAIN	CUTOFF
9300K	R G B	R G B SUB
6500K	R G B	R G B SUB
5500K	R G B	R G B SUB
FULL-SIZE :	H V	
LINEARITY :	H V V-BAL	
EXIT ALIGNTOF		63%

Fig. 2.3

- 7.1 Connect the video input, set brightness control at 50% and contrast at minimum position, Vg2 at Minimum (counter clockwise, and ABL (3647, potentiometer) at center position. Slowly increase Vg2 voltage until light output is at 0.17Ft-L +/- 0.05Ft-L (Y=0.17Ft-L, on the screen of CA-100) .
- 7.2 (The screen of monitor is dark now)
  - : Press " " to show the OSD menu as shown in Fig. 2.1.
  - : Select the character "FACTORY MODE" to access the R/G/B adjustment as shown in Fig. 2.2 and Fig. 2.3.
  - : Adjust the cutoff of R/G/B to get 9300K (x=0.281 +/- 0.015, y=0.311 +/- 0.015), and brightness output at 0.17 +/- 0.05 Ft-L (Y=0.17Ft-L).
- 7.3 : Press " " to set contrast at maximum (100%).
  - : Adjust gain of R/G/B to get 9300K (x=0.281 +/- 0.015, y=0.311 +/- 0.015, don't care about the Y value)
- 7.4 Apply a small white square 60 x 60 mm pattern, or 8% fill of full screen, brightness set to center (50%), and contrast at maximum (100%), adjust sub-contrast control (OSD) to reach 32 +/- 2 Ft-L.
- 7.5 : Select the 6500K colour temperature as shown in Fig. 2.2.
  - : Adjust the R/G/B cutoff and R/G/B gain as shown in procedure 7.2~7.4 to get R/G/B cutoff
 
$$\begin{aligned} x &= 0.313 \pm 0.015 \\ y &= 0.329 \pm 0.015 \\ Y &= 0.17 \pm 0.05 \text{ Ft-L} \end{aligned}$$
  - R/G/B gain
 
$$\begin{aligned} x &= 0.313 \pm 0.015 \\ y &= 0.329 \pm 0.015 \\ Y &= 28 \pm 2 \text{ Ft-L} \end{aligned}$$

- 7.6 : Select the 5500K colour temperature as shown in Fig. 2.2.
  - : Adjust the R/G/B cutoff & R/G/B gain as procedure 7.2~7.4

to get R/G/B cutoff
 
$$\begin{aligned} x &= 0.332 \pm 0.015 \\ y &= 0.347 \pm 0.015 \\ Y &= 0.17 \pm 0.05 \text{ Ft-L} \end{aligned}$$

R/G/B gain
 
$$\begin{aligned} x &= 0.332 \pm 0.015 \\ y &= 0.347 \pm 0.015 \\ Y &= 25 \pm 2 \text{ Ft-L} \end{aligned}$$

- 7.7 Apply full white pattern at 9300K, adjust ABL R3647 to reach 32 +/- 2 Ft-L (21") (contrast at maximum, brightness at maximum).

## 8. Picture geometry setting (factory pre-set modes)

- Apply a video signal with cross-hatch pattern.
- Apply a video signal in the 1024 x 768 with 69 kHz/85 Hz mode.
- Set brightness and contrast controls to their center positions (OSD control).

- 8.1 Horizontal geometry (OSD control)
  - Adjust the H-width to 380 mm (for 21" monitor).
  - Adjust the H-phase to center position.

- 8.2 Vertical geometry (OSD control)
  - Adjust vertical size to 285 mm (for 21" monitor).
  - Adjust V-phase to center position.

- 8.3 Trapezoid distortion (OSD control)
  - Adjust the trapezoid to get optimal vertical lines.

- 8.4 Pincushion (OSD control)
  - Adjust the pincushion to get optimal vertical line.

- 8.5 Parallelogram (OSD control)
  - Adjust parallelogram so that vertical lines are vertical or symmetrically about the center vertical axis.

- 8.6 Unbalance-pin (OSD control)
  - Adjust the unbalance-pin so that that vertical border lines are aligned symmetrically.

- 8.7 Rotation (OSD control)
  - Adjust picture so that vertical tilt is less than +/- 0.5mm.

- 8.8 Store the preset results by selecting the "exit" (OSD control).

- 8.9 Repeat the procedure 8.1 to 8.8 until all the preset timings have been adjusted completely

## 9. Focus adjustment

- : Apply a video signal in the 1024 x 768 with 69 kHz/85 Hz mode.
- : Select " @ " pattern.
- : Set the brightness at center (50%) and the contrast at maximum (100%).
- : Adjust focus potentiometers (top of L.O.T.) Focus 1 for horizontal focus and Focus 2 for vertical focus so that the picture at 2/3 of the diagonal lines (from center to four corners) of the displayed screen is as sharp as possible.

## 10. Loading DDC code

The DDC HEX data should be written into the DDC C (7331) by EEPROM writer or equivalent method.


- a: Service DDC Kit
  - DDC Module (DDC cable), Part number = 4822 320 1004
  - DDCV2N.EXE software (3.5" disk), Part number = 4822 711 0002 4
- b: Please refer to Service information 4822 727 21995 for using the Service DDC Kit.

# USB Connections

## If you have Windows '95...

follow these steps to complete setting up your monitor.

1. Start Windows '95 and install CD ROM supplied with this monitor.
2. Click on the "START" icon. Next, click on the "SETTINGS" icon. Then click on "CONTROL PANEL."
3. Double-click on "DISPLAY" icon. Next, click on "SETTINGS" tab. Then click on "ADVANCED PROPERTIES" dialog box.
4. Click on "MONITOR" tab.
- 5.(a) If you have an old computer, click on "CHANGE" dialog box. Next, "SELECT DEVICE" screen appears. Now click on "HAVE DISK" dialog box. and select CD-ROM drive  
Or
- 5.(b) If you have a new computer, "SELECT DEVICE" screen automatically appears. Click on "HAVE DISK" dialog box and select CD-ROM drive.
6. Select "OK" in the "INSTALL FROM DISK" dialog box. If model name of the Philips monitor is correct, click "OK" tab in the "SELECT DEVICE" dialog box.
7. Click "CLOSE" tab in the "ADVANCED PROPERTIES" dialog box. If your Windows'95 version is different or you need more detailed installation information, please refer to the windows '95 user's manual. **For additional information on the monitor, please refer to the owner's manual.**




## USB CONNECTIONS

USB (Universal Serial Bus ) is an innovation in connecting your IBM- compatible computer to your monitor. By using the USB, you will be able to connect your keyboard, mouse, printer, and other peripherals to your monitor instead of having to connect them to your computer. This will give you greater flexibility in setting up your system. Plus, you will have true plug-and-play capability. While the software is still being developed, Philips has included the hardware so you will be ready to take advantage of this next generation in computer development.

For an IBM-compatible Computer:

1. Turn off the computer.
2. Connect the (optional) USB Hub and cable to the computer and to the monitor. (Computer must have USB port.)
3. Connect the power cable.
4. Turn on the monitor. Then turn on the computer.
5. With the installation of the correct software, you will be able to connect specially-made peripherals to the monitor.

Note : USB Hub and cables sold separately. USB Bay exists in back of monitor.




## Use the information file (philips.inf) for Windows '95 (Philips Monitors-Driver Disk)

Philips' monitors build in VESA DDC1/2B feature to support Plug & Play requirement for Windows'95. You can install this information file (philips.inf) in order to select your Philips monitor from "Monitor" dialog box in Windows 95 to activate Plug & Play application. The installation procedure based on Windows '95 OEM Release 2 is specified as follows,



1. Start Windows'95
2. Click the 'Start' button, point to 'Settings', and then click 'Control Panel'
3. Double-click the 'Display' icon, select the 'Settings' tab, then select "Advanced Properties" tab.
4. Select "Ok" in the "Install From Disk" dialog box.
5. Now, you can see the Philips monitor is appeared.
6. If the model name of Philips monitor is correct, click "Ok" tab in "Select Device" dialog box.
7. Then, click "Close" tab in "Advanced Properties" dialog box.
8. Now, you can select "Refresh Rate" to change monitor resolution

If your Windows'95 version is different or you need more detail installation information, please refer to Windows 95 user's manual.


# Quick Reference for OSD Adjustment


















## Quick Reference for OSD Adjustment (Continued)












Quick Reference for OSD Adjustment (Continued)





# Quick Reference for OSD Adjustment (Continued)





"When rotary default setting selected"





# Mechanical Adjustments

# Wiring diagram

## 0. Location of the panel

- 0.1 Main panel (1156)
- 0.2 Video panel (1157)
- 0.3 Terminal panel (1159)
- 0.4 USB panel (1160) - optional
- 0.5 Encoder panel (1162)
- 0.6 Power switch panel (1163)

## 1. General

To be able to perform measurements and repairs on the circuit boards, the monitor should be placed in **Service Position (Fig. 3.1)** first:

*How to remove the back cover of monitor:*

There are 4 screws [2 screws are at the rear of the monitor, the other two screws are on the bottom of the monitor] to fix the front cabinet and back cover of the monitor.

Step 1: Remove the "cable cover" as shown in Fig. 3.2.

Step 2: Remove 2 screws (rear view) as shown in Fig. 3.3.

Step 3: Turn the set to remove the other 2 screws, as shown in Fig. 3.4.

Step 4: Turn the set to its original position.

Step 5: Remove back cover (\* There are two "plastic clips" on the "front cabinet" to hold the "rear cover" as shown in Fig. 3.5).

*Chassis :*

After removing the back cover, you can see the inside the monitor with metal frame and metal shield.

- Remove 26 screws for service position as Fig. 3.6 to Fig. 3.15.

## Video panel :

- After removing the metal frames, remove the metal shielding on rear side of Video panel for measurement.

## Main panel :

After removing the metal frames,

- Disconnect "Video panel"
- Disconnect EHT cable (EHT cap)
- Disconnect 4 pin connector "M1501" (wire of YOKE, on Main panel)
- Disconnect 2 pin connector "M1114" (degaussing coil, on Main panel)
- Disconnect 1 pin connector "M1701" (on Video panel)
- Disconnect 2 pin connector "M1219" (on Main panel)
- Disconnect 9 pin connector "M1217" (on Main panel)
- Disconnect 3 pin connector "M1213" (on Main panel)
- Disconnect 3 pin connector "M1504" (on Main panel)
- Disconnect 2 pin connector "M1218" (on Main panel)
- Disconnect 2 pin connector "M1220" (on Main panel)
- Disconnect 7 pin connector "M1212" (on Main panel)

- To slide out Main panel.

- Remove 2 screws as shown in Fig. 3.14, then push the clips to the right as shown in Fig. 3.13, to separate the bottom plate.

- Remove the plastic frame as shown in Fig. 3.15.

- Remove the "Rotary panel" "Earphone panel" from

Front cabinet and place it on the table as shown in Fig. 3.1.
















- Connect all the connectors and panels for service position.












## Service position :

Place monitor in service position as shown in Fig. 3.1 through Fig. 3.15.








## 2. Repair instructions

After the service position is obtained, all the panel's copper trace sides may be accessed.






## Block Diagram






Video Panel C.B.A. (A)






Power Switch Panel C.B.A. (G)



























Power Switch Panel C.B.A. (G)




# Terminal Schematic Diagram


**A1**









## Waveforms



# Video


A2






1701	A21	3748	B18
1702	G1	3749	C18
1703	G1	3750	D18
1704	F23	3751	E18
1705	L24	3752	F18
1706	M24	3753	G18
1707	N24	3754	H18
1708	J24	3755	I18
1709	K24	3756	J18
1710	L24	3757	K18
1711	M24	3758	L18
1712	N24	3759	M18
1713	J24	3760	N18
1714	K24	3761	O18
1715	L24	3762	P18
1716	M24	3763	Q18
1717	N24	3764	R18
1718	J24	3765	S18
1719	K24	3766	T18
1720	L24	3767	U18
1721	M24	3768	V18
1722	N24	3769	W18
1723	J24	3770	X18
1724	K24	3771	Y18
1725	L24	3772	Z18
1726	M24	3773	A19
1727	N24	3774	B19
1728	J24	3775	C19
1729	K24	3776	D19
1730	L24	3777	E19
1731	M24	3778	F19
1732	N24	3779	G19
1733	J24	3780	H19
1734	K24	3781	I19
1735	L24	3782	J19
1736	M24	3783	K19
1737	N24	3784	L19
1738	J24	3785	M19
1739	K24	3786	N19
1740	L24	3787	O19
1741	M24	3788	P19
1742	N24	3789	Q19
1743	J24	3790	R19
1744	K24	3791	S19
1745	L24	3792	T19
1746	M24	3793	U19
1747	N24	3794	V19
1748	J24	3795	W19
1749	K24	3796	X19
1750	L24	3797	Y19
1751	M24	3798	Z19
1752	N24	3799	A20
1753	J24	3800	B20
1754	K24	3801	C20
1755	L24	3802	D20
1756	M24	3803	E20
1757	N24	3804	F20
1758	J24	3805	G20
1759	K24	3806	H20
1760	L24	3807	I20
1761	M24	3808	J20
1762	N24	3809	K20
1763	J24	3810	L20
1764	K24	3811	M20
1765	L24	3812	N20
1766	M24	3813	O20
1767	N24	3814	P20
1768	J24	3815	Q20
1769	K24	3816	R20
1770	L24	3817	S20
1771	M24	3818	T20
1772	N24	3819	U20
1773	J24	3820	V20
1774	K24	3821	W20
1775	L24	3822	X20
1776	M24	3823	Y20
1777	N24	3824	Z20
1778	J24	3825	A21
1779	K24	3826	B21
1780	L24	3827	C21
1781	M24	3828	D21
1782	N24	3829	E21
1783	J24	3830	F21
1784	K24	3831	G21
1785	L24	3832	H21
1786	M24	3833	I21
1787	N24	3834	J21
1788	J24	3835	K21
1789	K24	3836	L21
1790	L24	3837	M21
1791	M24	3838	N21
1792	N24	3839	O21
1793	J24	3840	P21
1794	K24	3841	Q21
1795	L24	3842	R21
1796	M24	3843	S21
1797	N24	3844	T21
1798	J24	3845	U21
1799	K24	3846	V21
1800	L24	3847	W21


A25 1010-13

2 V/div AC  
5 uS/div


A30 7001-18

1 V/div AC  
5 uS/div


A26 1010-14

2 V/div AC  
5 mS/div


A31 7001-17

0.1 V/div AC  
5 uS/div


A27 7001-24

20 mV/div AC  
5 mS/div


A32 7001-14

2 V/div AC  
5 mS/div


A28 7001-22

2 V/div AC  
5 uS/div


A29 7001-21

1 V/div AC  
5 uS/div


A29 7001-19

1 V/div AC  
5 uS/div

A29 7001-15

1 V/div AC  
5 uS/div


# B1









# Deflection






B41 7604-E




5 V/div AC  
5 uS/div

B48 7632-D




100 V/div AC  
5 uS/div

B55 7523-D




2 V/div AC  
5 uS/div

B42 7605-C




0.2 V/div AC  
5 uS/div

B49 5638-9




100 V/div AC  
5 uS/div

B56 5522-6




5 V/div AC  
5 uS/div

B43 7601-6




5 V/div AC  
5 uS/div

B50 5638-3




100 V/div AC  
5 uS/div

B57 5522-1




100 V/div AC  
5 uS/div

B44 7633-D




5 V/div AC  
5 uS/div

B51 5638-8




5 V/div AC  
5 uS/div

B58 7543-D




100 V/div AC  
5 uS/div

B45 7633-G




5 V/div AC  
5 uS/div

B52 7522-G




5 V/div AC  
5 uS/div

B59 5523-7




50 V/div AC  
5 uS/div

B46 7643-G




5 V/div AC  
5 uS/div

B53 7522-D



1 V/div AC  
5 uS/div

B60 7551-C




50 V/div AC  
5 uS/div

B47 7634-D



100 V/div AC  
5 uS/div

B54 7523-G



5 V/div AC  
5 uS/div


B61 7550-C




50 V/div AC  
5 uS/div



B3




B62 3553




50 V/div AC  
5 uS/div

B63 5651




20 V/div AC  
10 uS/div

B64 565




50 V/div AC  
10 uS/div

B65 765




50 mV/div  
10 uS/div

B66 765




2 V/div AC  
5 uS/div

B67 7652




0.5 V/div  
10 uS/div

B68 7436



10 V/div  
5 mS/div

# Waveforms




B62 3553




50 V/div AC  
5 uS/div

B63 5651-10




20 V/div AC  
10 uS/div

B64 5651-4




50 V/div AC  
10 uS/div

B65 7651-C




50 m V/div AC  
10 uS/div

B66 7651-B




2 V/div AC  
5 uS/div

B67 7652-E




0.5 V/div AC  
10 uS/div

B68 7436-C




10 V/div AC  
5 mS/div

B69 7676-D




0.5 V/div AC  
5 uS/div

B70 7671-D




0.5 V/div AC  
5 uS/div

B71 7672-D



0.2 V/div AC  
5 uS/div

B72 7673-D



0.2 V/div AC  
5 uS/div

B73 7674-D




0.2 V/div AC  
5 uS/div

B74 7675-D




0.2 V/div AC  
5 uS/div

B75 7591-3




1 V/div AC  
10 uS/div

B76 7591-1




1 V/div AC  
10 uS/div

B77 7203-2




0.5 V/div AC  
10 uS/div

B78 7203-10




2 V/div AC  
50 nS/div

B79 7203-13




2 V/div AC  
5 uS/div

B80 7203-29




2 V/div AC  
5 uS/div

B81 6243-N




0.2 V/div AC  
5 uS/div


B82 7257-C




50 m V/div AC  
10 uS/div

## Power Supply







C1 6904-N

50 mV/div AC  
5 uS/div


C8 5162-9

2 V/div AC  
5 uS/div


C15 7111-3

20 V/div AC  
5 mS/div


C2 5136-6

10 V/div AC  
2 uS/div


C9 5162-7

2 V/div AC  
5 uS/div


C16 7111-20

20 V/div AC  
5 mS/div

C3 5136-9

10 V/div AC  
2 uS/div


C10 5136-5

100 V/div AC  
2 mS/div


C17 7111-14

20 V/div AC  
5 mS/div


C4 5162-1

10 V/div AC  
5 uS/div


C11 5136-4

100 V/div AC  
2 mS/div


C18 7111-5

20 V/div AC  
5 mS/div


C5 5162-3

10 V/div AC  
5 uS/div


C12 5136-2

20 V/div AC  
5 uS/div


C19 5162-18

20 V/div AC  
5 mS/div


C6 5162-2

10 V/div AC  
5 uS/div


C13 7131-C

20 V/div AC  
5 mS/div


C20 5162-17

50 V/div AC  
5 uS/div


C7 5162-6

2 V/div AC  
5 uS/div

C14 7112-D


20 V/div AC  
5 mS/div

C21 7162-G

10 V/div AC  
5 uS/div

## Waveforms for Diagram C

C22 5162-16




5 V/div AC  
10 uS/div

C29 7144-10




20 V/div AC  
5 uS/div

C23 5162-15




50 V/div AC  
5 uS/div

C30 7144-5




10 V/div AC  
5 mS/div

C24 7168-G




10 V/div AC  
5 uS/div

C31 7144-4




10 V/div AC  
5 mS/div

C25 7168-S




20 V/div AC  
5 mS/div

C32 7144-2




10 V/div AC  
5 mS/div

C26 5162-11




20 V/div AC  
5 uS/div

C33 7144-1




10 V/div AC  
5 mS/div

C27 7172-5




20 V/div AC  
5 mS/div

C34 7146-5




10 V/div AC  
5 mS/div

C28 7144-8



20 V/div AC  
5 mS/div

C35 7146-3




10 V/div AC  
5 mS/div


0140 B 7 7191 J 13 0529 C 18 3557 B 8 3250 C 2 3112 J 11 2202 L 3 1181 L 16  
0141 B 8 7192 D 11 0524 C 7 3558 B 9 3257 C 3 3113 J 12 2203 K 4 1182 H 14  
0142 B 9 7193 E 10 0525 F 10 3559 A 5 3258 C 4 3114 I 12 2204 K 4 1183 K 10  
0143 B 10 7194 F 11 0526 G 11 3560 B 6 3259 D 5 3115 I 12 2205 L 4 1184 B 7  
0144 F 5 7144 L 7 0527 C 7 3561 B 7 3260 C 2 3117 I 12 2206 K 4 1185 B 3  
0145 F 6 7145 L 8 0528 D 8 3562 A 4 3261 B 3 3118 I 12 2207 J 3 1186 K 1  
0146 B 5 7146 K 9 0529 E 9 3563 A 4 3262 B 4 3119 I 11 2208 E 4 1187 C 1  
0147 B 6 7147 K 10 0530 F 10 3564 A 4 3263 C 5 3120 J 11 2209 F 4 1188 D 1  
0148 B 7 7172 I 11 0531 G 11 3565 B 7 3264 C 6 3121 J 12 2210 F 4 1189 E 1  
0149 C 8 7181 H 8 0532 H 12 3566 A 5 3265 D 7 3122 K 12 2211 B 4 1190 E 1  
0150 B 12 7182 I 9 0533 I 13 3567 C 7 3266 E 8 3123 J 12 2212 B 4 1191 C 1  
0151 B 11 7183 J 10 0534 J 14 3568 C 8 3267 L 3 3124 K 11 2213 B 4 1192 D 4  
0152 B 7 7184 K 11 0535 K 15 3569 D 9 3268 M 4 3125 J 11 2214 E 3 1193 A 1  
0153 F 11 7185 L 12 0536 L 16 3570 E 10 3269 N 5 3126 J 12 2215 E 3 1214 K 2  
0154 E 12 7281 A 4 0115 J 11 3571 F 11 3270 F 6 3127 J 11 2216 E 3 1215 J 2  
0155 F 5 7282 B 5 0116 K 12 3572 G 12 3271 G 7 3128 J 11 2217 F 4 1216 F 11  
0156 F 6 7283 C 6 0117 L 13 3573 G 13 3272 H 8 3129 J 11 2218 F 4 1217 F 11  
0157 F 7 7284 D 7 0118 M 14 3574 H 14 3273 I 9 3130 K 12 2219 F 4 1218 F 11  
0158 H 8 7285 E 8 0119 N 15 3575 I 15 3274 J 10 3131 K 12 2220 F 4 1219 F 11  
0159 G 9 7286 F 9 0120 O 16 3576 J 16 3275 K 11 3132 L 13 2221 F 4 1220 L 3  
0160 B 10 7287 G 10 0121 P 17 3577 K 17 3276 L 12 3133 K 12 2222 F 4 1221 L 4  
0161 F 11 7288 H 11 0122 Q 18 3578 L 18 3277 M 13 3134 L 13 2223 F 4 1222 L 4  
0162 K 12 7289 I 12 0123 R 19 3579 M 19 3278 N 14 3135 L 13 2224 F 4 1223 A 1  
0163 C 2 7290 J 13 0124 S 20 3580 N 20 3279 O 15 3136 M 14 2225 F 4 1224 L 4  
0164 B 1 7317 E 4 0125 T 21 3581 O 21 3280 P 16 3137 N 14 2226 F 4 1225 L 4  
0165 B 2 7318 F 5 0126 U 22 3582 P 22 3281 Q 17 3138 N 14 2227 F 4 1226 L 4  
0166 B 3 7319 G 6 0127 V 23 3583 Q 23 3282 R 18 3139 N 14 2228 F 4 1227 L 4  
0167 H 4 7320 H 7 0128 W 24 3584 R 24 3283 S 19 3140 N 14 2229 F 4 1228 L 4  
0168 B 5 7321 I 8 0129 X 25 3585 S 25 3284 T 20 3141 N 14 2230 F 4 1229 L 4  
0169 B 6 7322 J 9 0130 Y 26 3586 T 26 3285 U 21 3142 N 14 2231 F 4 1230 L 4  
0170 B 7 7323 K 10 0131 Z 27 3587 U 27 3286 V 22 3143 N 14 2232 F 4 1231 L 4  
0171 B 8 7324 L 11 0132 AA 28 3588 V 28 3287 W 23 3144 N 14 2233 F 4 1232 L 4  
0172 B 9 7325 M 12 0133 AB 29 3589 W 29 3288 X 24 3145 N 14 2234 F 4 1233 L 4  
0173 B 10 7326 N 13 0134 AC 30 3590 X 30 3289 Y 25 3146 N 14 2235 F 4 1234 L 4  
0174 B 11 7327 O 14 0135 AD 31 3591 Y 31 3290 Z 26 3147 N 14 2236 F 4 1235 L 4  
0175 B 12 7328 P 15 0136 AE 32 3592 Z 32 3291 AA 27 3148 N 14 2237 F 4 1236 L 4  
0176 B 1 7329 Q 16 0137 AF 33 3593 AA 33 3292 AB 28 3149 N 14 2238 F 4 1237 L 4  
0177 B 2 7330 R 17 0138 AG 34 3594 AB 34 3293 AC 29 3150 N 14 2239 F 4 1238 L 4  
0178 B 3 7331 S 18 0139 AH 35 3595 AC 35 3294 AD 30 3151 N 14 2240 F 4 1239 L 4  
0179 B 4 7332 T 19 0140 AI 36 3596 AD 36 3295 AE 31 3152 N 14 2241 F 4 1240 L 4  
0180 B 5 7333 U 20 0141 AJ 37 3597 AE 37 3296 AF 32 3153 N 14 2242 F 4 1241 L 4  
0181 B 6 7334 V 21 0142 AK 38 3598 AF 38 3297 AG 33 3154 N 14 2243 F 4 1242 L 4  
0182 B 7 7335 W 22 0143 AL 39 3599 AG 39 3298 AH 34 3155 N 14 2244 F 4 1243 L 4  
0183 B 8 7336 X 23 0144 AM 40 3600 AH 40 3299 AI 35 3156 N 14 2245 F 4 1244 L 4  
0184 B 9 7337 Y 24 0145 AN 41 3601 AI 41 3300 AJ 36 3157 N 14 2246 F 4 1245 L 4  
0185 B 10 7338 Z 25 0146 AO 42 3602 AJ 42 3301 AK 37 3158 N 14 2247 F 4 1246 L 4  
0186 B 11 7339 AA 26 0147 AP 43 3603 AK 43 3302 AL 38 3159 N 14 2248 F 4 1247 L 4  
0187 B 12 7340 AB 27 0148 AQ 44 3604 AL 44 3303 AM 39 3160 N 14 2249 F 4 1248 L 4  
0188 B 1 7341 AC 28 0149 AR 45 3605 AM 45 3304 AN 40 3161 N 14 2250 F 4 1249 L 4  
0189 B 2 7342 AD 29 0150 AS 46 3606 AN 46 3305 AO 41 3162 N 14 2251 F 4 1250 L 4  
0190 B 3 7343 AE 30 0151 AT 47 3607 AO 47 3306 AP 42 3163 N 14 2252 F 4 1251 L 4  
0191 B 4 7344 AF 31 0152 AU 48 3608 AP 48 3307 AQ 43 3164 N 14 2253 F 4 1252 L 4  
0192 B 5 7345 AG 32 0153 AV 49 3609 AQ 49 3308 AR 44 3165 N 14 2254 F 4 1253 L 4  
0193 B 6 7346 AH 33 0154 AW 50 3610 AR 50 3309 AS 45 3166 N 14 2255 F 4 1254 L 4  
0194 B 7 7347 AI 34 0155 AX 51 3611 AS 51 3310 AT 46 3167 N 14 2256 F 4 1255 L 4  
0195 B 8 7348 AJ 35 0156 AY 52 3612 AS 52 3311 AU 47 3168 N 14 2257 F 4 1256 L 4  
0196 B 9 7349 AK 36 0157 AZ 53 3613 AT 53 3312 AV 48 3169 N 14 2258 F 4 1257 L 4  
0197 B 10 7350 AL 37 0158 BA 54 3614 AT 54 3313 AW 49 3170 N 14 2259 F 4 1258 L 4  
0198 B 11 7351 AM 38 0159 BB 55 3615 AT 55 3314 AX 50 3171 N 14 2260 F 4 1259 L 4  
0199 B 12 7352 AN 39 0160 BC 56 3616 AT 56 3315 AY 51 3172 N 14 2261 F 4 1260 L 4  
0200 B 1 7353 AO 40 0161 BD 57 3617 AT 57 3316 AZ 52 3173 N 14 2262 F 4 1261 L 4  
0201 B 2 7354 AP 41 0162 BE 58 3618 AT 58 3317 BA 53 3174 N 14 2263 F 4 1262 L 4  
0202 B 3 7355 AQ 42 0163 BF 59 3619 AT 59 3318 BB 54 3175 N 14 2264 F 4 1263 L 4  
0203 B 4 7356 AR 43 0164 BG 60 3620 AT 60 3319 BC 55 3176 N 14 2265 F 4 1264 L 4  
0204 B 5 7357 AS 44 0165 BH 61 3621 AT 61 3320 BD 56 3177 N 14 2266 F 4 1265 L 4  
0205 B 6 7358 AE 45 0166 BI 62 3622 AT 62 3321 BE 57 3178 N 14 2267 F 4 1266 L 4  
0206 B 7 7359 AF 46 0167 BJ 63 3623 AT 63 3322 BF 58 3179 N 14 2268 F 4 1267 L 4  
0207 B 8 7360 AG 47 0168 BK 64 3624 AT 64 3323 BG 59 3180 N 14 2269 F 4 1268 L 4  
0208 B 9 7361 AH 48 0169 BL 65 3625 AT 65 3324 BH 60 3181 N 14 2270 F 4 1269 L 4  
0209 B 10 7362 AI 49 0170 BM 66 3626 AT 66 3325 BI 61 3182 N 14 2271 F 4 1270 L 4  
0210 B 11 7363 AJ 50 0171 BN 67 3627 AT 67 3326 BJ 62 3183 N 14 2272 F 4 1271 L 4  
0211 B 12 7364 AK 51 0172 BO 68 3628 AT 68 3327 BK 63 3184 N 14 2273 F 4 1272 L 4  
0212 B 1 7365 AL 52 0173 BP 69 3629 AT 69 3328 BL 64 3185 N 14 2274 F 4 1273 L 4  
0213 B 2 7366 AM 53 0174 BQ 70 3630 AT 70 3329 BM 65 3186 N 14 2275 F 4 1274 L 4  
0214 B 3 7367 AN 54 0175 BR 71 3631 AT 71 3330 BN 66 3187 N 14 2276 F 4 1275 L 4  
0215 B 4 7368 AO 55 0176 BS 72 3632 AT 72 3331 BO 67 3188 N 14 2277 F 4 1276 L 4  
0216 B 5 7369 AP 56 0177 BT 73 3633 AT 73 3332 BP 68 3189 N 14 2278 F 4 1277 L 4  
0217 B 6 7370 AQ 57 0178 BU 74 3634 AT 74 3333 BQ 69 3190 N 14 2279 F 4 1278 L 4  
0218 B 7 7371 AR 58 0179 BV 75 3635 AT 75 3334 BR 70 3191 N 14 2280 F 4 1279 L 4  
0219 B 8 7372 AS 59 0180 BW 76 3636 AT 76 3335 BS 71 3192 N 14 2281 F 4 1280 L 4  
0220 B 9 7373 AT 60 0181 BX 77 3637 AT 77 3336 BT 72 3193 N 14 2282 F 4 1281 L 4  
0221 B 10 7374 AU 61 0182 BY 78 3638 AT 78 3337 BU 73 3194 N 14 2283 F 4 1282 L 4  
0222 B 11 7375 AV 62 0183 BZ 79 3639 AT 79 3338 BV 74 3195 N 14 2284 F 4 1283 L 4  
0223 B 12 7376 AW 63 0184 CA 80 3640 AT 80 3339 BW 75 3196 N 14 2285 F 4 1284 L 4  
0224 B 1 7377 AX 64 0185 CB 81 3641 AT 81 3340 BX 76 3197 N 14 2286 F 4 1285 L 4  
0225 B 2 7378 AY 65 0186 CC 82 3642 AT 82 3341 CA 81 3198 N 14 2287 F 4 1286 L 4  
0226 B 3 7379 AZ 66 0187 CD 83 3643 AT 83 3342 CB 82 3199 N 14 2288 F 4 1287 L 4  
0227 B 4 7380 BA 67 0188 CE 84 3644 AT 84 3343 CC 83 3200 N 14 2289 F 4 1288 L 4  
0228 B 5 7381 BB 68 0189 CF 85 3645 AT 85 3344 CD 84 3201 N 14 2290 F 4 1289 L 4  
0229 B 6 7382 BC 69 0190 CG 86 3646 AT 86 3345 CE 85 3202 N 14 2291 F 4 1290 L 4  
0230 B 7 7383 BD 70 0191 CH 87 3647 AT 87 3346 CF 86 3203 N 14 2292 F 4 1291 L 4  
0231 B 8 7384 BE 71 0192 CI 88 3648 AT 88 3347 CG 87 3204 N 14 2293 F 4 1292 L 4  
0232 B 9 7385 BF 72 0193 CJ 89 3649 AT 89 3348 CH 88 3205 N 14 2294 F 4 1293 L 4  
0233 B 10 7386 BG 73 0194 CK 90 3650 AT 90 3349 CI 89 3206 N 14 2295 F 4 1294 L 4  
0234 B 11 7387 BH 74 0195 CL 91 3651 AT 91 3350 CJ 90 3207 N 14 2296 F 4 1295 L 4  
0235 B 12 7388 BI 75 0196 CM 92 3652 AT 92 3351 CK 91 3208 N 14 2297 F 4 1296 L 4  
0236 B 1 7389 BJ 76 0197 CN 93 3653 AT 93 3352 CL 92 3209 N 14 2298 F 4 1297 L 4  
0237 B 2 7390 BK 77 0198 CO 94 3654 AT 94 3353 CM 93 3210 N 14 2299 F 4 1298 L 4  
0238 B 3 7391 BL 78 0199 CP 95 3655 AT 95 3354 CN 94 3211 N 14 2300 F 4 1299 L 4  
0239 B 4 7392 BM 79 0200 CQ 96 3656 AT 96 3355 CO 95 3212 N 14 2301 F 4 1300 L 4  
0240 B 5 7393 BN 80 0201 CR 97 3657 AT 97 3356 CP 96 3213 N 14 2302 F 4 1301 L 4  
0241 B 6 7394 BO 81 0202 CS 98 3658 AT 98 3357 CQ 97 3214 N 14 2303 F 4 1302 L 4  
0242 B 7 7395 BP 82 0203 CT 99 3659 AT 99 3358 CR 98 3215 N 14 2304 F 4 1303 L 4  
0243 B 8 7396 BQ 83 0204 CU 100 3660 AT 100 3359 CT 99 3216 N 14 2305 F 4 1304 L 4  
0244 B 9 7397 BR 84 0205 CV 101 3661 AT 101 3360 CU 100 3217 N 14 2306 F 4 1305 L 4  
0245 B 10 7398 BS 85 0206 CW 102 3662 AT 102 3361 CV 101 3218 N 14 2307 F 4 1306 L 4  
0246 B 11 7399 BT 86 0207 CX 103 3663 AT 103 3362 CW 102 3219 N 14 2308 F 4 1307 L 4  
0247 B 12 7400 BU 87 0208 CY 104 3664 AT 104 3363 CX 103 3220 N 14 2309 F 4 1308 L 4  
0248 B 1 7401 BV 88 0209 CZ 105 3665 AT 105 3364 CY 104 3221 N 14 2310 F 4 1309 L 4  
0249 B 2 7402 BW 89 0210 DA 106 3666 AT 106 3365 CZ 105 3222 N 14 2311 F 4 1310 L 4  
0250 B 3 7403 BX 90 0211 DB 107 3667 AT 107 3366 DA 106 3223 N 14 2312 F 4 1311 L 4  
0251 B 4 7404 BY 91 0212 DC 108 3668 AT 108 3367 DB 107 3224 N 14 2313 F 4 1312 L 4  
0252 B 5 7405 BZ 92 0213 DD 109 3669 AT 109 3368 DC 108 3225 N 14 2314 F 4 1313 L 4  
0253 B 6 7406 CA 93 0214 DE 110 3670 AT 110 3369 DD 109 3226 N 14 2315 F 4 1314 L 4  
0254 B 7 7407 CB 94 0215 DF 111 3671 AT 111 3370 DE 110 3227 N 14 2316 F 4 1315 L 4  
0255 B 8 7408 CC 95 0216 DG 112 3672 AT 112 3371 DF 111 3228 N 14 2317 F 4 1316 L 4  
0256 B 9 7409 CD 96 0217 DH 113 3673 AT 113 3372 DG 112 3229 N 14 2318 F 4 1317 L 4  
0257 B 10 7410 CE 97 0218 DI 114 3674 AT 114 3373 DH 113 3230 N 14 2319 F 4 1318 L 4  
0258 B 11 7411 CF 98 0219 DJ 115 3675 AT 115 3374 DI 114 3231 N 14 2320 F 4 1319 L 4  
0259 B 12 7412 CG 99 0220 DK 116 3676 AT 116 3375 DJ 115 3232 N 14 2321 F 4 1320 L 4  
0260 B 1 7413 CH 100 0221 DL 117 3677 AT 117 3376 DK 116 3233 N 14 2322 F 4 1321 L 4  
0261 B 2 7414 CI 101 0222 DM 118 3678 AT 118 3377 DL 117 3234 N 14 2323 F 4 1322 L 4  
0262 B 3 7415 CH 102 0223 DN 119 3679 AT 119 3378 DM 118 3235 N 14 2324 F 4 1323 L 4  
0263 B 4 7416 CJ 103 0224 DO 120 3680 AT 120 3379 DN 119 3236 N 14 2325 F 4 1324 L 4  
0264 B 5 7417 CK 104 0225 DP 121 3681 AT 121 3380 DO 120 3237 N 14 2326 F 4 1325 L 4  
0265 B 6 7418 CL 105 0226 DQ 122 3682 AT 122 3381 DP 121 3238 N 14 2327 F 4 1326 L 4  
0266 B 7 7419 CM 106 0227 DR 123 3683 AT 123 3382 DQ 122 3239 N 14 2328 F 4 1327 L 4  
0267 B 8 7420 CN 107 0228 DS 124 3684 AT 124 3383 DR 123 3240 N 14 2329 F 4 1328 L 4  
0268 B 9 7421 CO 108 0229 DT 125 3685 AT 125 3384 DS 124 3241 N 14 2330 F 4 1329 L 4  
0269 B 10 7422 CP 109 0230 DU 126 3686 AT 126 3385 DT 125 3242 N 14 2331 F 4 1330 L 4  
0270 B 11 7423 CQ 110 0231 DV 127 3687 AT 127 3386 DU 126 3243 N 14 2332 F 4 1331 L 4  
0271 B 12 7424 CR 111 0232 DW 128 3688 AT 128 3387 DV 127 3244 N 14 2333 F 4 1332 L 4  
0272 B 1 7425 CS 112 0233 DX 129 3689 AT 129 3388 DW 128 3245 N 14 2334 F 4 1333 L 4  
0273 B 2 7426 CT 113 0234 DY 130 3690 AT 130 3389 DX 129 3246 N 14 2335 F 4 1334 L 4  
0274 B 3 7427 CU 114 0235 EZ 131 3691 AT 131 3390 DY 130 3247 N 14 2336 F 4 1335 L 4  
0275 B 4 7428 CV 115 0236 FA 132 3692 AT 132 3391 EZ 131 3248 N 14 2337 F 4 1336 L 4  
0276 B 5 7429 CW 116 0237 FB 133 3693 AT 133 3392 FA 132 3249 N 14 2338 F 4 1337 L 4  
0277 B 6 7430 CX 117 0238 FC 134 3694 AT 134 3393 FB 133 3250 N 14 2339 F 4 1338 L 4  
0278 B 7 7431 CY 118 0239 FD 135 3695 AT 135 3394 FC 134 3251 N 14 2340 F 4 1339 L 4  
0279 B 8 7432 CZ 119 0240 FE 136 3696 AT 136 3395 FD 135 3252 N 14 2341 F 4 1340 L 4  
0280 B 9 7433 DA 120 0241 FF 137 3697 AT 137 3396 FE 136 3253 N 14 2342 F 4 1341 L 4  
0281 B 10 7434 DB 121 0242 FG 138 3698 AT 138 3397 FF 137 3254 N 14 2343 F 4 1342 L 4  
0282 B 11 7435 DC 122 0243 FH 139 3699 AT 139 3398 FG 138 3255 N 14 2344 F 4 1343 L 4




# Main Panel C.B.A. (B1, B2, B3, C and D)




## D

[illegible]








5353 F 1	2397 C 2	1341 F 4
5357 D 3	3341 F 3	1342 F 3
5359 D 3	3342 F 4	1343 F 1
5368 D 2	3343 F 3	1344 F 4
6370 D 3	3344 F 3	1345 E 3
6371 A 2	3345 F 2	1346 A 3
6372 A 1	3346 E 2	1349 F 2
6373 B 3	3347 E 3	1353 F 1
6374 B 3	3348 F 3	1368 D 2
6375 E 2	3349 F 2	2341 E 4
6376 D 2	3350 F 2	2342 F 3
6377 E 2	3351 F 2	2343 F 3
6378 E 3	3352 F 1	2344 E 3
6390 B 3	3353 F 1	2345 E 2
7341 D 3	3354 F 1	2346 E 3
7370 B 2	3355 E 2	2347 F 1
7371 B 3	3356 F 1	2348 F 1
7372 B 4	3357 E 3	2349 E 2
7373 C 3	3358 E 4	2350 E 1
7380 B 2	3359 E 3	2351 E 1
7381 A 2	3360 E 3	2352 F 4
7385 A 2	3361 E 3	2353 E 1
7391 C 2	3362 E 3	2354 F 4
7395 C 3	3363 E 2	2357 E 3
	3364 E 2	2358 D 3
	3365 E 2	2359 D 3
	3366 E 2	2360 D 2
	3367 E 2	2360 D 3
	3368 D 3	2370 D 3
	3369 D 3	2371 B 3
	3370 D 3	2372 B 3
	3371 C 3	2373 C 3
	3372 B 2	2374 A 2
	3374 B 4	2375 D 3
	3375 D 2	2376 A 2
	3377 E 2	2378 A 2
	3379 D 2	2380 B 3
	3381 B 2	2381 B 2
	3382 B 2	2382 E 2
	3380 A 3	2383 E 1
	3387 B 2	2385 B 3
	3388 B 3	2386 A 2
	3391 C 2	2387 B 2
	3392 C 2	2390 A 3
	3396 C 2	2391 C 2
	3397 C 2	2392 E 4
	5341 F 3	2393 E 3
	5345 F 2	2395 C 3
	5349 F 2	2396 C 3



## Key Control



Rotary Panel



## 0. Warning

All ICs and many other semi-conductors are susceptible to electrostatic discharges (ESD). Careless handling during repair can reduce life drastically. When repairing, make sure that you are connected with the same potential as the mass of the unit via a wrist wrap with resistance. Keep components and tools also at the same potential !

## 1. Servicing of SMDs (Surface Mounted Devices)

### 1.1 General cautions on handling and storage

- Oxidation on the terminals of SMDs results in poor soldering. Do not handle SMDs with bare hands.
- Avoid using storage places that are sensitive to oxidation such as places with sulphur or chlorine gas, direct sunlight, high temperatures or a high degree of humidity. The capacitance or resistance value of the SMDs may be affected by this.
- Rough handling of circuit boards containing SMDs may cause damage to the components as well as the circuit boards. Circuit boards containing SMDs should never be bent or flexed. Different circuit board materials expand and contract at different rates when heated or cooled and the components and/or solder connections may be damaged due to the stress. Never rub or scrape chip components as this may cause the value of the component to change. Similarly, do not slide the circuit board across any surface.

### 1.2 Removal of SMDs

- Heat the solder (for 2-3 seconds) at each terminal of the chip. By means of litz wire and a slight horizontal force, small components can be removed with the soldering iron. They can also be removed with a solder sucker (see Fig. 1A)




Fig. 1

- While holding the SMD with a pair of tweezers, take it off gently using the soldering iron's heat applied to each terminal (see Fig. 1 B).
- Remove the excess solder on the solder lands by means of litz wire or a solder sucker (see Fig. 1C).

### 1.3 Caution on removal

- When handling the soldering iron, use suitable pressure and be careful.
- When removing the chip, do not use undue force with the pair of tweezers.
- The soldering iron to be used (approx. 30 W) should preferably be equipped with a thermal control (soldering temperature: 225 to 250 °C).
- The chip, once removed, must never be reused.

### 1.4 Attachment of SMDs

- Locate the SMD on the solder lands by means of tweezers and solder the component on one side. Ensure that the component is positioned correctly on the solder lands (see Fig. 2A).
- Next complete the soldering of the terminals of the component (see Fig. 2B).

## MOUNTING




Fig. 2

## 2. Caution when attaching SMDs

- When soldering the SMD terminals, do not touch them directly with the soldering iron. The soldering should be done as quickly as possible, care must be taken to avoid damage to the terminals of the SMDs themselves.
- Keep the SMD's body in contact with the printed board when soldering.
- The soldering iron to be used (approx. 30 W) should preferably be equipped with a thermal control (soldering temperature: 225 to 250 °C).
- Soldering should not be done outside the solder land.
- Soldering flux (of rosin) may be used, but should not be acidic.
- After soldering, let the SMD cool down gradually at room temperature.
- The quantity of solder must be proportional to the size of the solder land. If the quantity is too great, the SMD might crack or the solder lands might be torn loose from the printed board (see Fig. 3).

## EXAMPLES





Fig. 3

## Exploded View



# Spare parts list

21" CM5800

29

## Parts indicated on exploded view: Model: 21A582BH/00C 21B582BH/00C

1	3138 107 95020	FRONT CAB. ASSY
	3138 104 40740	LENS
	3138 104 40750	FUNCTION KNOB
	3138 104 42680	LOCKER (L)
2	3138 104 40760	ROTARY KNOB
4	3138 101 63950	CRT MOUNTING WASHER
5	3138 100 41320	SCREW
6	3138 101 64480	CRT PLATE
8	3138 104 39380	POWER KNOB
	3138 104 40780	CABLE COVER
10	3138 107 95040	CABLE COVER ASSY
	3138 104 40990	NAME PLATE
25	3138 107 95030	BOTTOM PLATE ASSY
	3138 104 40670	BOTTOM PLATE
	3138 104 38270	SLIDER
	3138 104 39290	BASE - PEDESTAL
26	3138 104 40680	BACK COVER
	3138 104 41710	USB COVER
1051A	4822 131 11292	CRT M51LEQ183X61(F U)
1160	3138 128 63680	MAN PCB ASSY (for 21B582BH/00C)
1160	3138 128 63730	MAN PCB ASSY (for 21A582BH/00C)
1162	3138 128 63690	VIDEO PCB ASSY
1163	3138 128 63700	ENCODER PCB ASSY
1164	4822 212 11701	DC SWITCH PCB ASSY
1170	3138 128 63720	TERMINAL PCB ASSY

### Various

1055A	3138 178 72110	DEGAUSSING COIL
	3138 106 51710	CARTON
	3138 106 51680	CUSHION - TOP LEFT
	3138 106 51690	CUSHION - TOP RIGHT
	3138 106 51700	CUSHION - BOTTOM
	4822 701 14028	P.E. BAG
	3138 117 01000	CD-ROM
		COLORIFIC
	3138 105 35610	D.F.U
	3138 105 35200	QUICK SET UP GUIDE
	3138 105 35330	QUICK SET UP GUIDE
	4822 265 11089	VGA ADP
		HD15/DB15(MAC, HIGH-END)
	3138 105 34910	EUR. WARRANTY BOOKLET
	4822 701 15012	P.E. BAG
	4822 701 20292	TAPPING SCREW WITH WASHER

### Accessories

1115A	4822 321 11297	MAINS CORD (SHIELDING)
1054	3138 178 71150	I/F CABLE

## 1160 Main Panel

### Various

1160	3138 128 63680	MAN PCB ASSY (for 21B582BH/00C)
1160	3138 128 63730	MAN PCB ASSY (for 21A582BH/00C)
	4822 492 71337	SPRING (FUSE HOLDER)

	4822 701 20292	TAPPING SCREW WITH WASHER
	5322 390 20011	VET SILIC.P4 20GR
1101A	4822 070 34002	FUSE, 218004.(4A)
1102A	4822 280 70378	RELAY 2P 12V/60MA OMI-SS212 B
1103	3138 128 78430	AC INLET ASSY
1201	4822 267 10696	14P MALE (62511B)
1202	4822 242 10836	12.000 000 MHz
1213	4822 267 10742	7P. MALE
1214	4822 265 31209	3P
1216	4822 267 10704	8P FEMALE
	4822 466 93161	INSULATION PLATE
	4822 466 92891	INSULATING PLATE
	5322 390 20011	VET SILIC.P4 20GR
1291	5322 255 40958	8-DIP-S-LC
1293	4822 265 10672	42P FEM.
1591	4822 265 31231	3 P MALE
1901	4822 265 30891	2 P.



1266	3138 128 64700	EEPROM IC ASS'Y (for 21B582BH/00C)
1266	3138 128 64710	EEPROM IC ASS'Y (for 21A582BH/00C)

### II-

2104	4822 121 70446	220nF 20% 250V
2105	4822 121 10661	2.2nF 20% 400V
2106	4822 121 10661	2.2nF 20% 400V
2107	5322 121 44212	1μF 10% 275V
2111	4822 121 43641	470nF 5% 400V
2112	4822 121 43699	220nF 100V
2113	4822 121 43699	220nF 100V
2114	4822 124 80132	47μF 20% 25V
2115	4822 121 43695	47nF 10% 100V
2116	5322 122 32531	100pF 5% 50V
2117	4822 126 10453	50V
2118	4822 121 70547	1.5nF 5% 100V
2119	4822 124 22669	1μF 20% 50V
2120	4822 124 22669	1μF 20% 50V
2121	4822 121 43696	100nF 100V
2122	4822 121 10754	33nF 10% 400V

### II-

2123	4822 124 11517	450V 100U 20%
2124	4822 121 43696	100nF 100V
2125	4822 121 70357	22nF 10% 630V
2126	4822 121 70386	47nF 10% 250V
2127	4822 124 81186	47U 20% 20%
2128	4822 126 13196	100nF 10% SMD 25V
2129	4822 124 12112	1000μF 20% 10V
2130	4822 124 42145	100μF 20% 25V
2132	4822 124 12112	1000μF 20% 10V
2134	4822 124 12113	3300μF 20% 10V
2138A	4822 126 14088	2.2nF 20% 250V
2141	4822 124 22669	1μF 20% 50V
2142	4822 121 43693	10nF 100V
2143	4822 124 40239	0.47μF 20% 63V
2144	5322 122 32311	470pF 10% 100V
2146	4822 126 14107	330nF +80/20% 25V

2147	5322 122 32331	1nF 10% 100V
2148	4822 121 43696	100nF 100V
2149	4822 121 43913	470nF 10% 100V
2150	5322 122 32311	470pF 10% 100V

2154	4822 124 22678	100μF 20% 16V
2155	4822 124 42199	22μF 20% 50V
2157	4822 121 43908	47nF 10% 250V
2159	4822 121 43699	220nF 100V
2160	4822 126 13196	100nF 10% SMD 25V

2161	4822 126 12105	33nF 5% 63V
2163	4822 121 43908	47nF 10% 250V
2164	4822 121 10754	33nF 10% 400V

### II-

2165	4822 121 43699	220nF 100V
2166	4822 121 43696	100nF 100V
2167	4822 124 42359	47μF 100V

2168	4822 124 42149	220μF 20% 25V
2169	4822 124 42145	100μF 20% 25V
2170	4822 126 11103	10nF 5% 50V
2171	4822 121 43696	100nF 100V
2172A	4822 126 14088	2.2nF 20% 250V
2173	4822 126 13196	100nF 10% SMD 25V
2181	4822 124 11941	100μF 20% 250V
2182	4822 124 11941	100μF 20% 250V
2185	4822 124 12034	220μF 20% 100V
2186	4822 122 32899	100pF 10%B 500V
2187	4822 124 11942	2200μF 20% 25V
2188	4822 122 32899	100pF 10%B 500V
2189	4822 124 11943	1000μF 20% 25V
2190	4822 122 32899	100pF 10%B 500V
2191	4822 124 81285	2200μF 20% 16V
2193	4822 124 40849	330μF 20% 16V
2194	4822 124 42199	22μF 20% 50V
2195	4822 124 23441	10μF 20% 50V
2196	4822 124 22669	1μF 20% 50V
2197	5322 122 31866	6.8nF 10% 63V
2198	5322 122 32336	560pF 10% 100V
2199	4822 126 14076	220N 25V. P8020
2201	4822 126 13196	100nF 10% SMD 25V
2202	5322 122 32143	22pF 100V
2203	5322 122 32143	22pF 100V
2204	4822 126 14076	220N 25V. P8020
2218	5322 124 41817	220μF 16V

2219	5322 122 32659	33pF 5% 50V
2220	5322 122 32659	33pF 5% 50V
2221	4822 124 22681	47μF 20% 16V
2222	4822 122 33575	220pF 5% 50V
2234	5322 122 32658	22pF 5% 50V
2236	5322 122 32658	22pF 5% 50V
2237	5322 122 32531	100pF 5% 50V
2239	4822 124 40433	47μF 20% 25V
2244	4822 124 23539	10μF 20% 50V
2245	4822 126 13196	100nF 10% SMD 25V
2252	4822 126 12944	47nF 10% 50V
2254	4822 126 12944	47nF 10% 50V
2316	4822 126 14076	220N 25V. P8020
2317	4822 126 13196	100nF 10% SMD 25V
2325	4822 124 80132	47μF 20% 25V
2331	4822 126 13196	100nF 10% SMD 25V
2332	5322 122 32531	100pF 5% 50V
2333	5322 122 32531	100pF 5% 50V
2401	4822 122 33575	220pF 5% 50V
2402	4822 124 42172	1000μF 16V
2403	5322 122 32658	22pF 5% 50V
2404	4822 126 13196	100nF 10% SMD 25V
2411	4822 121 43696	100nF 100V
2412	4822 121 10755	8.2nF 5% 100V

### II-

2413	4822 126 13606	10N 2% 100V
2414	4822 122 32646	5.6nF 10% 50V
2415	4822 121 43696	100nF 100V
2416	4822 121 70312	150nF 10% 100V
2417	4822 121 70631	3.3nF 2.5% 100V
2418	4822 126 12944	47nF 10% 50V
2419	5322 122 32268	470pF 10% 50V
2423	4822 126 12944	47nF 10% 50V
2424	4822 124 42199	22μF 20% 50V
2425	4822 124 23441	10μF 20% 50V

2436	4822 121 70411	220nF 5% 250V
2437	4822 124 42145	100μF 20% 25V
2438	4822 122 33575	220pF 5% 50V
2441	5322 122 32531	100pF 5% 50V
2442	4822 126 13196	100nF 10% SMD 25V
2451	4822 124 22681	47μF 20% 16V
2452	5322 122 34123	1nF 10% 50V
2454	4822 121 43696	100nF 100V
2501	4822 124 42144	470μF 63V
2502	4822 124 22336	100μF 20% 40V

2503	4822 126 14106	220pF 5% 50V
2504	4822 121 43693	10nF 100V
2509	4822 121 43913	470nF 10% 100V
2510	4822 124 42144	470μF 63V
2519	4822 124 23539	10μF 20% 50V
2527	4822 124 22675	1μF 20% 160V
2528	4822 124 22675	1μF 20% 160V
2529	4822 126 13035	220pF 10% 2KV
2530	4822 126 13035	220pF 10% 2KV
2532	4822 121 10756	3.6nF 2% 2KV

### II-

2531	4822 121 43364	10nF 10% 400V
------	----------------	---------------

2533	4822 126 10783	100pF 5% 2KV
2536	4822 124 22681	47μF 20% 16V
2537	4822 121 43918	100nF 10% 400V
2538	4822 124 80834	100μF 20% 250V
2539	4822 122 33646	470pF 10% 500V
2541	4822 124 22681	47μF 20% 16V
2542	4822 124 22681	47μF 20% 16V
2554	4822 122 33968	1nF 5% 500V
2555	4822 121 43913	470nF 10% 100V

2557	4822 124 42145	100μF 20% 25V
2558	4822 124 42145	100μF 20% 25V
2559	4822 121 43696	100nF 100V
2590	4822 121 43696	100nF 100V
2593	4822 124 80132	47μF 20% 25V
2595	4822 124 80132	47μF 20% 25V
2596	4822 121 43696	100nF 100V
2601	4822 124 42199	22μF 20% 50V
2602	4822 121 43696	100nF 100V
2603	4822 124 23539	10μF 20% 50V

2604	4822 126 10453	50V
2605	4822 121 70162	10nF 5% 400V
2606	4822 122 33177	10nF 20% 50V
2607	4822 126 11099	100pF 5% 50V
2608	5322 122 32331	1nF 10% 100V
2609	4822 126 10453	50V
2611	4822 126 13196	100nF 10% SMD 25V
2614	4822 122 33891	3.3nF 10% 63V
2618	4822 121 43697	330nF 10% 100V
2619	4822 124 42357	33μF 25V

2642	4822 121 41893	33μF 10% 100V
2645	4822 126 13134	1μF 10% 1KV
2646	4822 121 40336	47nF 10% 250V
2648	4822 124 41659	47μF 20% 25V
2651	4822 126 14413	20pF 10% 2KV
2653	4822 126 13134	1μF 10% 1KV
2654	4822 126 13134	1μF 10% 1KV
2656	4822 126 12651	10nF 20% 2K
2657	4822 126 12651	10nF 20% 2K
2660	4822 126 13196	10nF 10% SMD 2V



3126	4822 050 22003	20k 1% 0.6W	3239	4822 050 23303	33k 1% 0.6W	3508	4822 050 24701	470Ω 1% 0.6W	3647	4822 100 11585	22k 30%LIN 0.1W
3127	4822 050 24704	470k 1% 0.6W	3240	4822 050 21001	100Ω 1% 0.6W	3509	4822 050 22208	2Ω 1% 0.6W	3648	4822 117 10833	10k 1% 0.1W
3128	4822 050 24704	470k 1% 0.6W	3241	4822 051 20101	100Ω 5% 0.1W	3510	4822 052 11228	2Ω 5% 0.5W	3649	4822 050 22702	2k7 1% 0.6W
3129	4822 050 29104	910k 1% 0.6W	3242	4822 050 21001	100Ω 1% 0.6W	3517	4822 051 20472	4k7 5% 0.1W	3650	4822 050 21203	12k 1% 0.6W
3130	4822 050 29104	910k 1% 0.6W	3243	4822 051 20008	0Ω JUMP. (SMD)	3518	4822 051 20223	22k 5% 0.1W	3651	4822 053 21224	220k 5% 0.5W
3131	4822 117 11744	0Ω 22 5% 1W	3244	4822 051 20822	8k2 5% 0.1W	3519	4822 051 20223	22k 5% 0.1W	3652	4822 111 50617	2k2 10% 0.5W
3132	4822 117 11744	0Ω 22 5% 1W	3246	4822 050 24702	4k7 1% 0.6W	3533	4822 050 21501	150Ω 1% 0.6W	3653	4822 053 21104	100k 5% 0.5W
3133	4822 117 11744	0Ω 22 5% 1W	3247	4822 051 20101	100Ω 5% 0.1W	3534	4822 050 24709	47Ω 1% 0.6W	3654	4822 050 25602	5k6 1% 0.6W
3134	5322 116 51882	0Ω jumper FR25)	3248	4822 051 20472	4k7 5% 0.1W	3535	4822 117 10833	10k 1% 0.1W	3655	4822 117 10118	1M 5% 0.5W
			3249	4822 050 24702	4k7 1% 0.6W	3536	4822 052 11279	27Ω 5% 0.5W	3656	4822 117 10118	1M 5% 0.5W
3136	4822 050 21004	100k 1% 0.6W				3537	4822 117 13284	390Ω 7W	3657	4822 050 21502	1k5 1% 0.6W
3137	4822 050 24708	4Ω 7 1% 0.6W				3538	4822 117 13285	2k2 3W			
			3250	4822 117 10833	10k 1% 0.1W	3540	4822 052 10828	8Ω 2 5% 0.33W	3658	4822 050 23302	3k3 1% 0.6W
			3251	4822 050 24702	4k7 1% 0.6W	3541	4822 050 24709	47Ω 1% 0.6W	3659	4822 050 21002	1k 1% 0.6W
			3252	4822 050 22201	220Ω 1% 0.6W	3542	4822 050 21003	10k 1% 0.6W	3660	4822 050 23903	39k 1% 0.6W
			3253	4822 050 24702	4k7 1% 0.6W				3661	4822 050 24701	470Ω 1% 0.6W
			3254	4822 050 22201	220Ω 1% 0.6W	3543	4822 050 21202	1k2 1% 0.6W	3662	4822 051 20223	22k 5% 0.1W
			3255	4822 050 21503	15k 1% 0.6W	3544	4822 052 11108	1Ω 5% 0.5W	3663	4822 053 21004	100k 5% 0.5W
3139	4822 050 21002	1k 1% 0.6W	3256	4822 051 20472	4k7 5% 0.1W	3545	4822 117 10442	10Ω 5%	3664	4822 117 10118	1M 5% 0.5W
3140	4822 050 23301	330Ω 1% 0.6W	3257	4822 117 11504	270Ω 1% 0.1W	3546	4822 117 12941	33Ω 5% 7W	3665	4822 051 20302	3k 5% 0.1W
3141	4822 050 21501	150Ω 1% 0.6W	3258	4822 051 20121	120Ω 5% 0.1W	3547	4822 117 13081	68Ω 1% 0.5W	3666	4822 050 21002	1k 1% 0.6W
3142	4822 050 24702	4k7 1% 0.6W	3259	4822 051 20332	3k3 5% 0.1W	3548	4822 052 10108	1Ω 5% 0.33W	3671	4822 051 20104	100k 5% 0.1W
3143	4822 050 23901	390Ω 1% 0.6W				3549	4822 052 10108	1Ω 5% 0.33W			
3144	4822 050 25602	5k6 1% 0.6W	3260	4822 050 22203	22k 1% 0.6W	3550	4822 050 26801	680Ω 1% 0.6W	3672	4822 051 20104	100k 5% 0.1W
3145	4822 050 25601	560Ω 1% 0.6W	3261	4822 050 21001	100Ω 1% 0.6W	3551	4822 100 11141	10k 30%lin 0.1W	3673	4822 051 20104	10k 1% 0.1W
3146	4822 050 11003	10k 1% 0.4W	3262	4822 050 21001	100Ω 1% 0.6W	3552	4822 050 26801	680Ω 1% 0.6W	3674	4822 051 20104	100k 5% 0.1W
3147	4822 050 21002	1k 1% 0.6W	3263	4822 050 21001	100Ω 1% 0.6W				3675	4822 051 20104	100k 5% 0.1W
3148	4822 117 10833	10k 1% 0.1W	3264	4822 050 21001	100Ω 1% 0.6W	3553	4822 117 12675	150Ω 5% 5W	3676	4822 051 20104	100k 5% 0.1W
			3265	4822 051 20008	0Ω JUMP. (SMD)	3554	4822 050 24701	470Ω 1% 0.6W	3677	4822 051 20008	0Ω JUMP. (SMD)
3149	4822 117 10833	10k 1% 0.1W	3316	4822 051 20472	4k7 5% 0.1W	3555	4822 117 12675	150Ω 5% 5W	3678	4822 051 20008	0Ω JUMP. (SMD)
3150	4822 050 21004	100k 1% 0.6W	3317	4822 051 20472	4k7 5% 0.1W	3556	4822 050 24701	470Ω 1% 0.6W	3679	4822 051 20008	0Ω JUMP. (SMD)
3151	4822 050 24703	47k 1% 0.6W	3318	4822 051 20154	150k 5% 0.1W	3557	4822 050 23909	39Ω 1% 0.6W	3680	4822 051 20008	0Ω JUMP. (SMD)
3152	4822 050 22709	27Ω 1% 0.6W	3321	4822 051 20472	4k7 5% 0.1W	3558	4822 052 11828	8Ω 2 5% 0.5W	3681	4822 051 20008	0Ω JUMP. (SMD)
3153	4822 050 22204	220k 1% 0.6W				3559	4822 050 24701	470Ω 1% 0.6W			
3154	4822 050 23303	33k 1% 0.6W	3323	4822 050 21002	1k 1% 0.6W	3560	4822 052 11828	8Ω 2 5% 0.5W	3685	4822 050 22202	2k2 1% 0.6W
3155	4822 050 21002	1k 1% 0.6W	3324	4822 117 11449	2k2 1% 0.1W	3561	4822 050 23909	39Ω 1% 0.6W	3686	4822 050 11003	10k 1% 0.4W
3156	4822 117 12672	0Ω 22 5% 2W	3325	4822 052 10478	4Ω 7 5% 0.33W	3562	4822 050 21001	100Ω 1% 0.6W	3687	4822 050 11003	10k 1% 0.4W
3157	4822 117 11973	15k 5% 1W	3331	4822 051 20101	100Ω 5% 0.1W				3688	4822 050 11003	10k 1% 0.4W
3158	4822 117 10833	10k 1% 0.1W	3332	4822 117 10834	47k 1% 0.1W	3563	4822 050 21203	12k 1% 0.6W	3689	4822 050 11003	10k 1% 0.4W
			3333	4822 117 10834	47k 1% 0.1W	3564	4822 050 22702	2k7 1% 0.6W	3690	4822 050 11003	10k 1% 0.4W
3159	4822 051 20884	680k 5% 0.1W	3334	4822 051 20101	100Ω 5% 0.1W	3565	4822 117 13286	2Ω 2 5W	3691	4822 050 11003	10k 1% 0.4W
3160	4822 050 22709	27Ω 1% 0.6W	3335	4822 051 20101	100Ω 5% 0.1W	3566	4822 117 11383	12k 1% 0.1W	3901	4822 116 21237	1M A/100V
3161	4822 050 11003	10k 1% 0.4W	3401	4822 051 20471	470Ω 5% 0.1W	3567	4822 050 24708	4Ω 7 1% 0.6W	3902	4822 116 40144	12Ω
3162	4822 050 24702	4k7 1% 0.6W	3402	4822 050 24701	470Ω 1% 0.6W	3568	4822 050 21002	1k 1% 0.6W	3911	4822 051 20109	10Ω 5% 0.1W
3163	4822 117 11973	15k 5% 1W				3569	4822 050 24708	4Ω 7 1% 0.6W			
3166	4822 050 22709	27Ω 1% 0.6W	3403	4822 050 21001	100Ω 1% 0.6W	3591	4822 050 11003	10k 1% 0.4W	3912	4822 050 24702	4k7 1% 0.6W
3168	4822 050 24702	4k7 1% 0.6W	3404	4822 117 10833	10k 1% 0.1W	3592	4822 050 21203	12k 1% 0.6W	3913	4822 116 82046	2k2 5% 1/6W
3169	4822 117 12671	0Ω 33 5% 5W	3405	4822 050 21001	100Ω 1% 0.6W	3593	4822 052 10479	47Ω 5% 0.33W	3914	4822 051 20102	1k 5% 0.1W
3170	4822 053 10108	1Ω 5% 1W	3406	4822 050 21001	100Ω 1% 0.6W				3916	4822 050 24701	470Ω 1% 0.6W
3171	4822 117 10834	47k 1% 0.1W	3408	4822 050 24701	470Ω 1% 0.6W	3594	4822 050 11003	10k 1% 0.4W			
			3409	4822 050 22202	2k2 1% 0.6W	3595	4822 052 10479	47Ω 5% 0.33W			
3172	4822 050 11003	10k 1% 0.4W	3410	4822 117 11449	2k2 1% 0.1W	3596	4822 050 24701	470Ω 1% 0.6W	5101	4822 157 71663	LINE TER
3173	4822 050 11003	10k 1% 0.1W	3411	4822 051 20332	3k3 5% 0.1W	3597	4822 050 22209	22Ω 1% 0.6W	5102	4822 157 71663	LINE TER
3174	4822 050 22704	270k 1% 0.6W	3412	4822 050 25101	510Ω 1% 0.6W	3598	4822 050 22202	2k2 1% 0.6W	5103	4822 526 10522	IND FXD BEAD
3175	4822 050 24303	43k 1% 0.6W	3413	4822 050 22702	2k7 1% 0.6W	3599	4822 050 23303	33k 1% 0.6W			
3176	4822 050 21502	1k5 1% 0.6W				3600	4822 117 10834	47k 1% 0.1W	5104	4822 526 10522	IND FXD BEAD
3181	4822 117 12755	120k 1%	3414	4822 050 24702	4k7 1% 0.6W	3601	4822 050 22202	2k2 1% 0.6W			
3182	4822 050 24703	47k 1% 0.6W	3415	4822 116 52257	22k 5% 0.5W	3602	4822 117 12755	120k 1%	5105	4822 526 10522	IND FXD BEAD
3183	4822 050 21808	1Ω 8 1% 0.6W	3416	4822 051 20472	4k7 5% 0.1W	3603	4822 050 21004	100k 1% 0.6W			
3188	4822 051 20474	470k 5% 0.1W	3417	4822 050 26803	68k 1% 0.6W				5106	4822 526 10522	IND FXD BEAD
3189	4822 050 24702	4k7 1% 0.6W	3418	4822 050 22204	220k 1% 0.6W	3604	4822 050 28202	8k2 1% 0.6W			
			3419	4822 050 26803	68k 1% 0.6W	3605	4822 050 22709	27Ω 1% 0.6W			
3190	4822 051 20224	220k 5% 0.1W	3421	4822 117 11383	12k 1% 0.1W	3607	4822 050 11003	10k 1% 0.4W	5111	3138 178 72070	PFC CHOKE
3191	4822 050 23301	330Ω 1% 0.6W	3422	4822 117 11449	2k2 1% 0.1W	3608	4822 051 20154	150k 5% 0.1W	5112	3138 178 72130	T CORE
3192	4822 050 21204	120k 1% 0.6W	3423	4822 051 20124	120k 5% 0.1W	3609	4822 051 20472	4k7 5% 0.1W	5136	3138 128 78010	USB
3193	4822 051 20102	1k 5% 0.1W	3424	4822 051 20008	0Ω JUMP. (SMD)	3611	4822 050 28201	820Ω 1% 0.6W			
3194	4822 101 11743	500Ω LIN CERMET				3612	4822 051 20562	5k6 5% 0.1W	5161	3138 128 73760	TRANSFORMER DRIVER
3195	4822 050 21202	1k2 1% 0.6W	3425	4822 050 24708	4Ω 7 1% 0.6W						
3196	4822 117 11507	6k8 1% 0.1W	3426	4822 117 11449	2k2 1% 0.1W	3613	4822 050 22201	220Ω 1% 0.6W			
3197	4822 050 21002	1k 1% 0.6W	3427	4822 051 20472	4k7 5% 0.1W	3614	4822 116 52257	22k 5% 0.5W			
3199	4822 051 20008	0Ω JUMP. (SMD)	3428	4822 117 10833	10k 1% 0.1W	3615	4822 116 52257	22k 5% 0.5W	5162	3138 178 72170	POWER TRANSFORMER
3201	4822 050 21003	10k 1% 0.6W	3429	4822 117 10833	10k 1% 0.1W						
			3436	4822 050 26802	68k 1% 0.6W	3616	4822 050 11003	10k 1% 0.4W	5221	4822 157 53189	CHOKE COIL
3202	4822 050 21003	10k 1% 0.6W	3437	4822 117 10833	10k 1% 0.1W	3617	4822 050 21002	1k 1% 0.6W			
3203	4822 051 20332	3k3 5% 0.1W	3438	4822 050 21503	15k 1% 0.6W	3618	4822 117 10834	47k 1% 0.1W	5222	4822 157 53189	CHOKE COIL
3204	4822 051 20332	3k3 5% 0.1W	3439	4822 051 20472	4k7 5% 0.1W	3619					

## 31

CS 98 590

2724 4822 121 70162 10nF 5% 400V  
 2725 4822 121 70162 10nF 5% 400V  
 2726 4822 121 70162 10nF 5% 400V  
 2728 5322 122 33861 120pF 10% 50V  
 2729 5322 122 32531 100pF 5% 50V  
 2730 4822 121 70162 10nF 5% 400V  
 2731 4822 126 14122 6.8nF 10% 50V  
 2732 4822 124 80606 1µF 20% 160V

2733 4822 126 13196 100nF 10% SMD 25V  
 2735 4822 126 13196 100nF 10% SMD 25V  
 2739 5322 122 32531 100pF 5% 50V  
 2740 5322 122 32531 100pF 5% 50V  
 2741 4822 124 42171 22µF 25V  
 2742 4822 121 70162 10nF 5% 400V  
 2743 4822 126 14122 6.8nF 10% 50V  
 2744 4822 124 80606 1µF 20% 160V  
 2745 4822 124 41751 47µF 20% 50V  
 2746 4822 124 40433 47µF 20% 25V

2747 4822 121 43693 10nF 100V  
 2748 4822 124 41634 22µF ELEC 16V  
 2749 4822 126 13196 100nF 10% SMD 25V  
 2750 4822 124 12184 10µF 20% 16V

—|—

2751 4822 124 80131 100µF 20% 25V  
 2752 5322 122 32654 22nF 10% 63V  
 2753 5322 122 32654 22nF 10% 63V  
 2754 4822 126 13692 47pF 1% 63V  
 2755 4822 124 80131 100µF 20% 25V  
 2756 4822 124 40433 47µF 20% 25V  
 2757 5322 124 40641 10µF 20% 100V  
 2760 5322 122 32658 22pF 5% 50V  
 2761 5322 122 32658 22pF 5% 50V  
 2762 5322 122 32658 22pF 5% 50V

2763 5322 122 32658 22pF 5% 50V  
 2764 4822 122 33177 10nF 20% 50V  
 2765 4822 126 13692 47pF 1% 63V  
 2766 5322 122 32658 22pF 5% 50V  
 2767 4822 122 33646 470pF 10% 500V  
 2768 4822 126 13196 100nF 10% SMD 25V

2769 4822 126 13196 100nF 10% SMD 25V

2770 4822 126 13196 100nF 10% SMD 25V

2771 4822 121 43693 10nF 100V  
 2772 4822 122 33968 1nF 5% 500V

2773 4822 126 12267 470pF 10%R(HR) 2KV

2774 4822 126 14102 10nF 20% 2KV  
 2776 4822 126 13196 100nF 10% SMD 25V

2777 4822 252 60127 DSP-201M-C04F  
 2778 4822 126 13196 100nF 10% SMD 25V

2779 4822 252 60127 DSP-201M-C04F  
 2780 4822 252 60127 DSP-201M-C04F  
 2781 4822 126 13196 100nF 10% SMD 25V

2782 4822 124 42169 470µF 25V  
 2783 4822 124 41634 22µF ELEC 16V  
 2784 4822 122 33177 10nF 20% 50V

2785 4822 126 13196 100nF 10% SMD 25V

2786 4822 126 13196 100nF 10% SMD 25V

2787 4822 126 13196 100nF 10% SMD 25V

2788 4822 126 13196 100nF 10% SMD 25V

2789 4822 126 13196 100nF 10% SMD 25V

2790 4822 122 33177 10nF 20% 50V  
 2793 4822 126 13196 100nF 10% SMD 25V

2794 4822 126 13196 100nF 10% SMD 25V

2795 4822 126 13196 100nF 10% SMD 25V

2796 4822 126 13196 100nF 10% SMD 25V

2797 4822 126 13196 100nF 10% SMD 25V

2798 4822 124 42169 470µF 25V

—|—

3704 4822 117 11507 6k8 1% 0.1W  
 3706 4822 051 20104 100k 5% 0.1W  
 3707 4822 050 16802 6k8 1% 0.4W  
 3708 4822 051 20102 1k 5% 0.1W  
 3710 4822 117 11507 6k8 1% 0.1W

3711 4822 051 20105 1M 5% 0.1W  
 3712 4822 051 20101 100k 5% 0.1W  
 3713 4822 051 20008 0Ω JUMP. (SMD)  
 3714 4822 051 20008 0Ω JUMP. (SMD)  
 3715 4822 051 20008 0Ω JUMP. (SMD)

3716 4822 051 20101 100k 5% 0.1W  
 3717 4822 051 20101 100k 5% 0.1W  
 3718 4822 051 20101 100k 5% 0.1W  
 3719 4822 051 20105 1M 5% 0.1W  
 3721 4822 051 20479 47k 5% 0.1W  
 3722 4822 051 20479 47k 5% 0.1W  
 3723 4822 051 20479 47k 5% 0.1W  
 3724 4822 117 11503 220k 1% 0.1W  
 3725 4822 051 20101 100k 5% 0.1W  
 3726 4822 051 20101 100k 5% 0.1W

3727 4822 051 20101 100k 5% 0.1W  
 3728 4822 051 20101 100k 5% 0.1W  
 3729 4822 117 11139 1k5 1% 0.1W  
 3730 4822 117 10833 10k 1% 0.1W  
 3735 4822 117 11449 2k2 1% 0.1W  
 3736 4822 051 20331 330k 5% 0.1W  
 3737 4822 051 20223 22k 5% 0.1W  
 3739 4822 051 20101 100k 5% 0.1W  
 3740 4822 050 24709 47k 1% 0.6W  
 3741 4822 051 20201 200k 5% 0.1W

3742 4822 051 20223 22k 5% 0.1W  
 3743 4822 117 11507 6k8 1% 0.1W  
 3744 4822 051 20274 270k 5% 0.1W  
 3745 4822 051 20109 10k 5% 0.1W  
 3746 4822 051 20223 22k 5% 0.1W  
 3747 4822 051 20223 22k 5% 0.1W  
 3748 4822 050 21005 1M 1% 0.6W  
 3749 4822 117 11503 220k 1% 0.1W  
 3750 4822 117 11503 220k 1% 0.1W  
 3751 4822 051 20113 11k 5% 0.1W

3752 4822 111 50618 82k 10% 0.5W  
 3753 4822 051 20113 11k 5% 0.1W  
 3754 4822 051 20331 330k 5% 0.1W  
 3755 4822 051 20113 11k 5% 0.1W  
 3757 4822 051 20101 100k 5% 0.1W  
 3758 4822 051 20201 200k 5% 0.1W  
 3760 4822 051 20479 47k 5% 0.1W  
 3761 4822 117 11507 6k8 1% 0.1W  
 3762 4822 051 20274 270k 5% 0.1W  
 3763 4822 051 20109 10k 5% 0.1W

3765 4822 051 20223 22k 5% 0.1W  
 3766 4822 050 21005 1M 1% 0.6W  
 3767 4822 051 20223 22k 5% 0.1W  
 3768 4822 051 20223 22k 5% 0.1W  
 3769 4822 111 50618 82k 10% 0.5W  
 3770 4822 051 20339 33k 5% 0.1W  
 3771 4822 051 20339 33k 5% 0.1W  
 3772 4822 051 20331 330k 5% 0.1W  
 3773 4822 051 20339 33k 5% 0.1W  
 3775 4822 051 20101 100k 5% 0.1W

3776 4822 051 20201 200k 5% 0.1W  
 3778 4822 117 11507 6k8 1% 0.1W  
 3779 4822 051 20274 270k 5% 0.1W  
 3780 5322 116 51882 0Ω jumper FR25)  
 3781 4822 051 20109 10k 5% 0.1W  
 3784 4822 050 21005 1M 1% 0.6W  
 3785 4822 051 20105 1M 5% 0.1W  
 3786 4822 051 20102 1k 5% 0.1W  
 3787 4822 111 50618 82k 10% 0.5W  
 3788 4822 117 11503 220k 1% 0.1W

3789 4822 051 20102 1k 5% 0.1W  
 3790 4822 051 20479 47k 5% 0.1W  
 3791 4822 117 10833 10k 1% 0.1W  
 3792 4822 051 20472 4k7 5% 0.1W  
 3793 4822 051 20105 1M 5% 0.1W  
 3794 4822 051 20561 560k 5% 0.1W  
 3795 4822 051 20132 1k3 5% 0.1W  
 3796 4822 051 20562 5k6 5% 0.1W SMD

3797 4822 051 20332 3k3 5% 0.1W  
 3798 4822 051 20102 1k 5% 0.1W

3799 4822 051 20101 100k 5% 0.1W  
 3801 4822 051 20101 100k 5% 0.1W  
 3802 4822 051 20101 100k 5% 0.1W  
 3803 4822 117 12993 0Ω01 100% 0.4W  
 3804 4822 051 20102 1k 5% 0.1W  
 3805 4822 051 20102 1k 5% 0.1W  
 3811 4822 050 21502 1k5 1% 0.6W  
 3812 4822 116 80548 15k 5% 0.5W  
 3814 4822 051 20008 0Ω JUMP. (SMD)  
 3815 4822 051 20008 0Ω JUMP. (SMD)

3816 4822 051 20008 0Ω JUMP. (SMD)  
 3819 4822 051 20331 330k 5% 0.1W  
 3821 4822 051 20331 330k 5% 0.1W  
 3823 4822 051 20331 330k 5% 0.1W

—|—

5702 4822 157 53519 IND FXD SP0406 A

5703 4822 152 20596 100U PM10 B  
 IND FXD SP0305 A  
 4U7 PM10 B

5704 4822 152 20596 IND FXD SP0305 A  
 4U7 PM10 B

5705 4822 152 20596 IND FXD SP0305 A  
 4U7 PM10 B

5706 3138 128 78040 COIL 0.15µH 10%

5707 3138 128 78040 COIL 0.15µH 10%

5708 3138 128 78040 COIL 0.15µH 10%

5709 4822 157 53189 CHOKE COIL  
 5.0µH PM10

5711 4822 152 20596 IND FXD SP0305 A  
 4U7 PM10 B

5712 4822 152 20596 IND FXD SP0305 A  
 4U7 PM10 B

5713 4822 152 20596 IND FXD SP0305 A  
 4U7 PM10 B

—|—

6702 4822 130 34382 BZX79-B8V2

6708 4822 130 42489 BYD33G

6709 4822 130 31878 1N4003G

6710 4822 130 80877 BAV103

6711 4822 130 80877 BAV103

6712 4822 130 80877 BAV103

—|—

7701 4822 209 16419 M52742SP

7702 4822 209 16103 LXC4389P1

7703 5322 209 11473 74HCT86N

7707 4822 209 16422 CVA4403

7708 4822 209 15329 CR6927

5322 390 20011 VET SILIC.P4  
 20GR

7709 4822 130 11231 CVA4502N

7725 5322 130 42136 BC848C

7727 5322 209 85913 MC7912CT

4822 526 10544 FERRITE BEAD  
 TR-3.5X1.3X6

1163 Encoder Panel

Various

1163 3138 128 63700 ENCODER PCB  
 ASSY

1247 4822 273 10348 ENCODER

1248 4822 276 13949 TACT SWITCH

—|—

6291 4822 130 83789 L-59GYC

3138 178 72510 CON. 8 PIN WIRE  
 HARNESS

1164 Switch Panel

Various

1164 4822 212 11701 DC SWITCH PCB  
 ASSY

1199 4822 276 13886 SWITCH 2P PUSH  
 BUTTON

## **The Introduction of CM5800, 21"** **Monitor**

- 0. Functional Block Diagram**
- 1. General Description**
- 2. Description of Circuit Diagram**
  - A.Power Supply / Power Saving Management**
  - B.Horizontal / Vertical Deflection**
  - C.Video board & DDC 1/2B**
  - D.Digital Circuit & Micro-controller**

### **1.GENERAL DESCRIPTION**

The CM5800, 21" is a Digital Controlled Auto-scan Color Display Monitor with high resolution. This monitor can operate at horizontal scan frequencies from 30 to 115 kHz and vertical scan frequencies from 50 to 160 Hz.

This monitor is equipped with an embedded micro-controller which can preset the required modes. The CM5800 provides many functions, such as digital adjustable picture, DDC1/2B, power management, low emission, high immunity ,etc.

This monitor complies with TCO low emission standard and also fulfills TCO'91 automatic power saving requirements. To reduce power consumption less than 15 watts in standby or suspend mode and less than 5 watts in off mod, the monitor also complies with energy star computer program initiated by the EPA.

### **2.DESRIPTION OF CIRCUIT DIAGRAM**

This description mainly introduces the functions, including power supply / power saving management, horizontal / vertical deflection, video amplifier, micro-controller, etc.

#### **A.POWER SUPPLY / POWER SAVING MANAGEMENT**

##### ***POWER SUPPLY:***

This monitor is designed as switch mode power supply which can operate mains input from 90 VAC to 264 VAC . The power supply uses an IC(L4990 ) for current mode PWM controller and drives the MOSFET switch directly. The control scheme transforms a switching converter from a voltage source into a multi-output voltage. The control concept is exhibited many desirable properties such as inherent over-load protection, stable and fast system response.

The maximum power consumption is up to 160 watts. A power limiting circuit is added for safety reason.

On main power supply circuit, secondary feedback via an photo-coupler is used to obtain a stable output voltage. The secondary feedback supplies all necessary voltages for deflection and video. On second power supply, voltage stabilizer IC is used to supply the small signals and micro-controller/EEPROM.

*POWER SAVING MANAGEMENT:*

This monitor can save power consumption while no sync pulses are detected by micro-controller and automatically recover to normal power when sync signals are detected by micro-controller.

During power saving mode, the second power supply still delivers 5V to  $\mu$ c. The consume power is less than 15 watts during standby / suspend modes, and less than 5 watts during off mode.

**B.HORIZONTAL / VERTICAL DEFLECTION***HORIZONTAL DEFLECTION:*

The heart of horizontal/vertical deflection controller is TDA4854 which can offer a complete and efficient small signal sync processing for auto-sync monitors. All functions are controlled by I2C bus.

This controller provides sync processing, which can accept separate, composite (H+V) and sync-on-video input signals. A very short setting time after mode change for protection of external power components has been taken.

The TDA4854 provides extensive functions like a flexible SMPS block and a geometry control with facilities, leading to excellent picture quality. This device also can directly drive the vertical deflection output stage, the line driver stage, the E/W output stage and the EHT stage. All controls are dc and tracked with the incoming frequencies.

The horizontal deflection is built around the buck converter which makes it possible to combine H-deflection and EHT generator and allows size and E/W correction without influencing EHT. Raster can be adjusted along horizontal direction by VR3551.

Transformer (LOT) generates the required 26.8kV anode voltage.

The adjustable focus (G3) and screen (G2) voltages are internally derived from the anode voltage. Other secondary windings are used to generate the voltages for G1. For 21 inch monitor also provides dynamic focus on G4 to get a good focus performance.(G4 also adjustable).

To guarantee constant EHT over the whole frequency range, the B+ is made tracked with H-frequency by means of a step down converter.

The horizontal size and east/west correction are obtained by varying the voltage of buck converter of the lower deflection a circuit.

Six-capacitors switch and dc controlled linearity coil are designed for optimal screen linearity.

For safety reasons, x-ray protection circuit is included, UC3842 will shut down EHT generator if the anode voltage exceeds a certain value(28.5kV).

This circuit is also used for beam current overload protection. Shut down EHT in case the total beam current exceeds a certain limit to protect both CRT and LOT.

***VERTICAL DEFLECTION:***

The majority of vertical deflection functions is integrated by two ICs ; TDA4854 and TDA8177.

The TDA4854 takes care of sync polarity correction ,automatic catching and holding of the vertical oscillator ,generation of saw-tooth drive current for vertical output and vertical s-correction ,and generation of a correct V-blanking pulse for video blanking during vertical retrace lines.

The TDA8177 which is a dc-coupled vertical deflection booster with differential input signals is suitable for color monitor. The output stage has thermal and soar protection ,and high linear saw-tooth signal amplification to obtain the required vertical deflection current.

To obtain a fast vertical retrace for non-VGA mode an external flyback supply is used.

**C.VIDEO AMPLIFIER & DDC 1/2B*****VIDEO AMPLIFIER:***

The heart of video circuit is M52742SP. This controller can drive the hybrid post-amp. CR6927 by buffer stage. The video DC level and gain at the cathode will be controlled by the software.

The red , green and blue video signals are amplified and inverted by the post-amplifier to output stage and AC coupled to the CRT cathodes.

Three cut-off adjustments are provided to set the video black level at cathode for all three guns. Also three individual gain adjustments are provided to adjust the white point at maximum swing. Both cut-off and gain controls are digit type control by micro-processor.

For limiting the beam current and preventing the local doming ,the beam current limit will automatically reduce the video swing in case the maximum beam current is exceeded.(ABL adjustment:R3647)

A spot-killer circuit is also added to prevent the CRT spot burn-in when the set is switched off.

***DDC 1/2B:***

Via SDA, the data about the information of the monitor , including the serial number , production codes ,CRT type and applicable timings are stored in the EEPROM (24IC21). To avoid picture interference ,the reading and writing processes are executed during vertical blanking which is informed by the vertical SYNC.

**D.MICROCONTROLLER*****GENERAL DESCRIPTION:***

The Philips P87C380 u-processor is used to control the monitor. The preset data are stored in EEPROM ST24W08.



# CM5800 21A BRIEF

## HARDWARE DEFINITION:

### a) KEY BOARD

There are one key pad and one rotary encoder at the front of monitor for the OSD control.

#### - OSD function key:

Push it, to confirm the entrance or exit from the OSD window

#### - Encoder:

To select or adjust the parameters which are chosen from OSD.


### b) OSD will DISAPPEAR and save automatically after non-operation

### c) Software will control the DPMS according to the SYNC status.

### d) VIDEO PRESET MODES

#### Pre-set Video Resolution and Sync Polarities

Resolution modes	H frequency	V frequency	H	V
640 x 400	31.5K	70Hz (VGA)	-	+
640 x 480	31.5K	60Hz (VGA)	-	-
640 x 480	37.5K	75Hz (VESA/75)	-	-
800 x 600	46.9K	75Hz (VESA/75)	+	+
800 x 600	53.7K	85Hz (VESA/85)	+	+
1024 x 768	60.0K	75Hz (VESA/75)	+	+
1024 x 768	68.7K	85Hz (VESA/85)	+	+
1152 x 870	69.0K	75Hz (MAC)	-	-
1152 x 900	71.8K	76Hz (SUN SPARC)	+	+
1280 x 1024	80.0K	75Hz (VESA/75)	+	+
1280 x 1024	91.0K	85Hz (VESA/85)	+	+
1600 x 1200	106.3K	85Hz (VESA/85)	+	+
1800 x 1350	105.45K	75Hz	+	+
1600 x 1200	112.5K	90Hz	+	+
1800 x 1440	112.5K	75Hz	+	+



## TABLE OF CONTENTS

21A582BH

21B582BH

### GETTING STARTED

Introduction .....	1
Safety .....	1
Description of Controls .....	2-3
Setting Up Guide .....	Foldout

### HOW TO USE THE ON SCREEN DISPLAY

#### MAIN CONTROLS WINDOW

Brightness .....	4
Contrast .....	4
Degauss .....	5

#### SCREEN SIZE & POSITION WINDOW

Full Size .....	6
Horizontal Position .....	6
Horizontal Size .....	7
Vertical Position .....	7
Vertical Size .....	7

#### COLOR TEMPERATURE WINDOW

9300 K CAD/CAM .....	8
6500 K DTP .....	8
5500 K Photo Retouch .....	8
User Presets .....	9

#### SPECIAL CONTROLS WINDOW

Language .....	10
Power Saving .....	10
OSD Controls .....	11
Video Input .....	11

#### ADVANCED CONTROLS WINDOW

Rotary Default .....	12
Moire .....	12
Vertical Linearity .....	13
Corner Correction .....	13

#### GEOMETRY CONTROLS WINDOW

Pincushion .....	14
Balanced Pincushion .....	14
Trapezoid .....	14
Parallelogram .....	14
Rotation .....	14
EXIT & RESET .....	15

### ADDITIONAL INFORMATION

BNC & USB Set Ups .....	16
Power Saving Feature .....	17
Pin Assignment .....	18
Specifications .....	18
Index .....	18
Glossary .....	18
Troubleshooting .....	19

### OTHER LANGUAGE VERSIONS

FRENCH (FRANCAIS) .....	20	ITALIAN (ITALIANO) .....	80
SPANISH (ESPAÑOL) .....	40	DUTCH (NEDERLANDS) .....	100
GERMAN (DEUTSCH) .....	60		

### Appendix

English	Information for Users in the U.S. ....	A1
	Declaration FCC .....	A2
	ENERGY DECLARATION .....	A3-A4
	Information for U.K. only .....	A5
	TCO'95 .....	A6-A7
Deutsch	Hinweis / GS .....	A8
Français	Declaration FCC .....	A9
Dansk	ADVASEL .....	A10
Norsk	ADVASEL .....	A10
Svenska	VARNING .....	A10
Suomi	VAROITUS .....	A10
Japanese	VCCI .....	A11

BECAUSE OF A POLICY OF CONTINUOUS PRODUCT IMPROVEMENT,  
THE INFORMATION MENTIONED IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE.

# Setting Up your Philips monitor

Installation de votre moniteur Philips.

Configuración de su monitor Philips.

This foldout is designed to help you use your monitor as soon as possible. Refer to your owner's manual for detailed information. You may also contact us at our web site: <http://www.monitors.be.philips.com>

Ce dépliant est conçu pour vous aider à utiliser votre moniteur du plus vite possible. Consulter votre manuel d'utilisateur pour des informations détaillées. Vous pouvez aussi nous contacter sur notre site Web: <http://www.monitors.be.philips.com>


Esta hoja plegable está diseñada para ayudarle a usar su monitor tan pronto como sea posible. Consulte su manual si desea información detallada. También puede comunicarse con nosotros a través de nuestra página web: <http://www.monitors.be.philips.com>

Because of a policy continuous product improvement, the information mentioned by this documents are subject to change without notice. Du fait de notre politique d'amélioration constante de nos produits, les spécifications ci-dessus sont sujettes à modification sans avis préalable. En el marco de la política de mejora continuada de nuestros productos, las especificaciones arriba indicadas están sujetas a cambio sin previo aviso.


To hook up your monitor to a Macintosh-type computer, follow the steps below. To hook up your monitor to an IBM-compatible computer, follow step 1, then turn over this foldout. In either case, before installing this monitor, please refer to the user's guide of your computer and video adapter to see if this equipment needs any additional setting.

Suivre les étapes suivantes pour connecter votre moniteur à un ordinateur du type Macintosh. Pour connecter votre moniteur à un ordinateur compatible IBM, suivre la première étape, puis tourner ce dépliant. En tout cas, avant l'installation de votre moniteur, veuillez vous référer au manuel d'utilisateur de votre ordinateur et carte vidéo pour voir si cet équipement a besoin d'installation supplémentaire.

Para conectar su monitor a un ordenador tipo Macintosh, siga los pasos que se presentan a continuación. Para conectar su monitor a un ordenador compatible con IBM, siga el paso 1, luego voltee esta página. En ambos casos, antes de instalar este monitor, consulte la guía del usuario de su ordenador y de su adaptador de vídeo, para comprobar si este equipo necesita alguna configuración adicional.




## **2** Connect the special Mac adapter (May not be included.) to one end of the monitor cable.



Connecter la carte spéciale Mac (pas toujours incluse) à une extrémité du câble du moniteur.

Conecte el adaptador especial de Mac (puede no estar incluido) a un extremo del cable del monitor.


## **3** Turn off the computer. Then connect the monitor cable.



Eteindre l'ordinateur, puis connecter le câble du moniteur.

Apague el ordenador. Luego conecte el cable del monitor.


## **4** Connect the power cable. Make sure the power plug and the wall socket are easily accessible.



Connecter le câble de puissance. S'assurer que la fiche secteur et la prise murale soient facilement accessibles.

Conecte el cable de energía. Verifique que se pueda acceder fácilmente al tomacorriente y al enchufe de pared.

## **5** Turn on the monitor. Then turn on the computer.



Allumer le moniteur, puis l'ordinateur.

Encienda el monitor. Luego encienda el ordenador.

# Setting Up your Philips monitor

Installation de votre moniteur Philips.

Configuración de su monitor Philips.


IBM-compatible computer hookup continued from step 1 on other side.

Connecter l'ordinateur compatible IBM, suite de la première étape de l'autre côté.

Conexión del ordenador compatible con IBM (continuación del paso 1 del otro lado de la página).

Monitor Model for Windows'95 Driver:  
Philips Brilliance 201P (Product ID: 21A58...)  
Philips Brilliance 201B (Product ID: 21B58...)


## 2 Turn off the computer. Then connect the monitor cable.



Eteindre l'ordinateur, puis connecter le câble du moniteur.

Apague el ordenador. Luego conecte el cable del monitor.


## 3 Connect the power cable. Make sure the power plug and the wall socket are easily accessible.



Connecter le câble de puissance. S'assurer que la fiche secteur et la prise murale soient facilement accessibles.

Conecte el cable de energía. Verifique que se pueda acceder fácilmente al tomacorriente y al enchufe de pared.

## 4 Turn on the monitor. Then turn on the computer.



Allumer le moniteur, puis l'ordinateur.

Encienda el monitor. Luego encienda el ordenador.

### If you have Windows '95 . . .

follow these steps to complete setting up your monitor.

1. Start Windows '95 and install CD ROM supplied with this monitor.
2. Click on the "START" icon. Next, click on the "SETTINGS" icon. Then click on "CONTROL PANEL."
3. Double-click on "DISPLAY" icon. Next, click on "SETTINGS" tab. Then click on "ADVANCED PROPERTIES" dialog box.
4. Click on "MONITOR" tab.
- 5a. If you have an old computer, click on "CHANGE" dialog box. Next, "SELECT DEVICE" screen appears. Now click on "HAVE DISK" dialog box, and select CD-ROM drive  
Or
- 5b. If you have a new computer, "SELECT DEVICE" screen automatically appears. Click on "HAVE DISK" dialog box and select CD-ROM drive.
6. Select "OK" in the "INSTALL FROM DISK" dialog box. If model name of the Philips monitor is correct, click "OK" tab in the "SELECT DEVICE" dialog box.
7. Click "CLOSE" tab in the "ADVANCED PROPERTIES" dialog box. If your Windows '95 version is different or you need more detailed installation information, please refer to the Windows '95 user's manual. **For additional information on the monitor, please refer to the owner's manual.**

### Si vous avez Windows '95 . . .

suivez les étapes suivantes pour terminer l'installation de votre moniteur.

1. Démarrer Windows 95 et installer le CD-ROM fourni avec votre moniteur.
2. Cliquer sur l'icône "DÉMARRER", ensuite, cliquer sur l'icône "PARAMETRES", puis cliquer sur l'icône "PANEAU DE CONFIGURATION".
3. Cliquer deux fois sur l'icône "AFFICHER", ensuite cliquer sur l'onglet "PARAMETRES", puis cliquer sur la boîte de dialogue "PROPRIETES AVANCEES".
4. Cliquer sur l'onglet "MONITEUR".
- 5a. Si vous avez un ancien ordinateur, cliquer sur la boîte de dialogue "CHANGER", ensuite l'écran "SELECTIONNER UNITE" apparaît. Maintenant cliquer sur la boîte de dialogue "DISQUETTE FOURNIE", et sélectionner le lecteur CD-ROM.
- OU
- 5b. Si vous avez un ordinateur récent, l'écran "SELECTIONNER UNITE" apparaît automatiquement. Cliquer sur la boîte de dialogue "DISQUETTE FOURNIE" et sélectionner le lecteur CD-ROM.
6. Sélectionner "OK" dans la boîte de dialogue "INSTALLER A PARTIR DE LA DISQUETTE". Si le nom du modèle de moniteur Philips est correct, cliquer sur l'onglet "OK" dans la boîte de dialogue "SELECTIONNER UNITE".
7. Cliquer sur l'onglet "FERMER" dans la boîte de dialogue "PROPRIETES AVANCEES". Si votre version Windows 95 est différente ou si vous voulez des informations plus détaillées sur l'installation, veuillez vous référer au manuel d'utilisateur de Windows 95. **Pour des informations complémentaires sur le moniteur, veuillez vous référer au manuel d'utilisateur.**

### WHAT TO DO IF YOUR MONITOR ISN'T WORKING

Make sure . . .

- ... the Power cable is plugged in the wall and the rear of the monitor.
- ... the Power button on top of the monitor should be in the ON position.
- ... the monitor cable is properly connected to the back of the monitor and the computer.
- ... to check to see if the monitor cable has bent pins.
- ... the D-Sub/BNC switch on the rear of the monitor is in the correct position. See pages 2 and 17 of the owner's manual for details.

See page 20 of the owner's manual for troubleshooting tips.

For warranty questions, please see your owner's manual.

### QUE FAIRE SI VOTRE MONITEUR NE MARCHE PAS

S'assurer . . .

- ... que le câble de puissance soit branché dans le mur et à l'arrière du moniteur.
- ... que le bouton Marche/Arrêt au dessus de votre moniteur soit sur MARCHE.
- ... que le câble du moniteur soit bien connecté à l'arrière du moniteur et de l'ordinateur.
- ... de vérifier que le câble du moniteur n'ait pas de fiches tordues.
- ... que l'interrupteur D-Sub/BNC à l'arrière du moniteur soit en position correcte. Voir page 24 et 39 de votre manuel d'utilisateur pour plus de détails.

Voir page 42 du manuel d'utilisateur pour des conseils de dépannage. Si vous avez des questions concernant la garantie, veuillez consulter votre manuel d'utilisateur.

### ¿QUÉ HACER SI SU MONITOR NO FUNCIONA?

Verifique . . .

- ... si el cable de energía está enchufado a la fuente de energía y a la parte posterior del monitor.
- ... si el botón de alimentación en la parte superior del monitor está en la posición ON.
- ... si el cable del monitor está debidamente conectado a la parte posterior del monitor y del ordenador.
- ... que las clavijas del cable del monitor no estén dobladas.
- ... que el interruptor D-Sub/BNC en la parte posterior del monitor esté en la posición correcta. Si desea más detalles, consulte las páginas 46 y 61 del manual del propietario.

En la página 64 del manual del propietario encontrará consejos sobre la localización de fallas.

Para consultas sobre la garantía, consulte el manual del propietario.


### Si tiene Windows '95 . . .

siga estos pasos para finalizar la configuración de su monitor.

1. Inicie Windows '95 e instale el CD ROM que se suministra con su monitor.
2. Haga clic en el icono "INICIO". Luego haga clic en el icono "CONFIGURACIÓN". Luego haga clic en "PANELO DE CONTROL".
3. Haga doble clic en el icono "PANTALLA". A continuación haga clic en la etiqueta "CONFIGURACIÓN" y luego en el cuadro de diálogo "PROPIEDADES AVANZADAS".
4. Haga clic en la etiqueta "MONITOR".
- 5a. Si usted tiene un ordenador viejo, haga clic en el cuadro de diálogo "CAMBIAR". Luego aparece la pantalla "SELECCIÓN DE DISPOSITIVO". Ahora haga clic en el cuadro de diálogo "UTILIZAR DISCO" y seleccione la unidad CD-ROM.
- OU
- 5b. Si tiene un ordenador nuevo, aparece automáticamente la pantalla "SELECCIONAR DISPOSITIVO". Haga clic en el cuadro de diálogo "UTILIZAR DISCO" y seleccione la unidad CD-ROM.
6. Seleccione "ACEPTAR" en el cuadro de diálogo "INSTALAR DESDE DISCO". Si el nombre del modelo del monitor Philips está correcto, haga clic en la etiqueta "ACEPTAR" del cuadro de diálogo "SELECCIÓN DE DISPOSITIVO".
7. Haga clic en la etiqueta "CERRAR" del cuadro de diálogo "PROPIEDADES AVANZADAS". Si su versión de Windows '95 es diferente o necesita información más detallada acerca de la instalación, consulte el manual del usuario de Windows '95. **Si desea información adicional acerca del monitor, consulte el manual del propietario.**



## INTRODUCTION AND SAFETY



### Introduction

The Philips Brilliance 201P/201B color monitor displays sharp and brilliant images of text and graphics with a maximum resolution of 1800x1440(201P), 1800x1350(201B) pixels. It is optimal for Windows, CAD / CAM / CAE, desktop publishing, spread sheets, multi-media, and any other application that demands a large screen size and high resolutions.

The monitor automatically scans horizontal frequencies from 30KHz to 115KHz(201P), 107KHz(201B), and vertical frequencies from 50Hz to 160Hz. With microprocessor-based digital-controlled circuitry and On-Screen Display (OSD) controls, the monitor can automatically adjust itself to the video card's scanning frequency and displays an image with the precise parameters you desire.

### Features

- An anti-glare, anti-static, and anti-reflection high-contrast screen coating eliminates any bad effects caused by room light reflecting on and dust attracted to the screen's surface.
- With the Color Adjustment feature, you can easily choose different preset color temperatures or set your own customized color parameters.
- The Image Tilt Adjustment feature corrects a rotated image. This correction minimizes the distortions caused by elements such as the Earth's magnetic field.
- The full-size feature expands the image on the monitor to fill the screen when used in factory preset modes.

- USB Bay at back of monitor is prepared for the Universal Serial Bus hub. You can easily and flexibly connect USB-designed devices – such as a mouse or keyboard – to the monitor for true Plug-and-Play function. USB hub sold separately (optional).

- Green Design – including automatic power saving function (NUTEK) and low-emission compliance (TCO '95) – shows your commitment to the environment.

- DDC1/DDC2B allows communication between the monitor and the PC for optimal video configuration.

- New CrystalClear technology for sharpest high brightness and high contrast

- Moire Cancellation eliminates diffraction, a fringe pattern in the picture.

**NOTE:** Your monitor operates according to the VESA DDC level 1/2B. Only computers that support the same guidelines and operate at the same or a higher level can make use of this feature. If your computer does not support the relevant guidelines, you can still use your monitor and computer. However, you may need to manually specify the appropriate resolution in the computer.

As an Energy Star Partner, Philips has determined that this product meets the Energy Star guidelines for energy efficiency.



Contact us at our web site: <http://www.monitors.be.philips.com>

### Safety precautions and maintenance

- Unplug the monitor, if you are not going to use it for an extended period of time.
- Unplug the monitor, if you need to clean it with a slightly damp cloth. Wiping the screen with a dry cloth is okay when the power is off. However, never use alcohol or ammonia-based liquids.
- Consult a service technician if the monitor does not operate normally when following the instructions in this manual.
- The back cover should be removed only by qualified service personnel.
- Keep the monitor out of direct sunlight and away from stoves or any other heat source.
- The top of the monitor is not a shelf. Remove any object that could fall into the vents or prevent proper cooling of the monitor's electronics.

- Keep the monitor dry. To avoid electric shock, do not expose it to rain or excessive moisture.
- Keep the monitor away from magnetic objects, such as speakers, electric motors, transformers, etc.
- When positioning the monitor, make sure the power plug and outlet are easily accessible.


### End-of-life disposal

Your new monitor contains materials that can be recycled and reused. Specialized companies can recycle your product to increase the amount of reusable materials and minimize the amount to be disposed of.


Please find out about the local regulations on how to dispose of your old monitor.

ENERGY STAR is an U.S. registered mark.


As an energy star partner, Philips has determined that this product meets the energy star guidelines for energy efficiency. IBM, IBM PC, and Power PC are registered trademarks of International Business Machines Corporation. Apple, Macintosh, Quadra, Performa, and Centris are registered trademarks of Apple Computer, Inc.



## DESCRIPTION OF CONTROLS




**CABLE COVER** – Snaps onto the back of the monitor to conceal cable connections. (Cable connections shown in the manual are without the cover on.)






## DESCRIPTION OF CONTROLS




### PEDESTAL



**PEDESTAL** – With the built-in pedestal, you can tilt and swivel the monitor to the most comfortable viewing angle. To best use your monitor, always place it at eye level.

**ON SCREEN DISPLAY** – Your monitor is preset at the factory. However, you can adjust it using the ON SCREEN DISPLAY button and the ROTARY knob described on page 2. The way to do so is through the On Screen Display (OSD). Below is a brief description of the six On Screen Display windows.



**MAIN CONTROLS** – The first window highlighted after the OSD has been selected. It has four features: BRIGHTNESS, CONTRAST and DEGAUSS. To adjust these features, turn to pages 4 - 5.

**SCREEN SIZE & POSITION** – The second window highlighted after the OSD has been selected. It has five features: FULL SIZE, HORIZONTAL POSITION, HORIZONTAL SIZE, VERTICAL POSITION, and VERTICAL SIZE. To adjust these features, turn to pages 6 - 7.


**COLOR TEMPERATURE** – The third window highlighted after the OSD has been selected. It has four features: CAD/CAM, DTP, PHOTO RETOUCH, and USER PRESETS. To adjust these features, turn to pages 8 - 9.


**GEOMETRY CONTROLS** – The sixth window highlighted after the OSD has been selected. It has five features: PINCUSHION, BALANCED PINCUSHION, TRAPEZOID, PARALLELOGRAM, and ROTATION. To adjust these features, turn to page 14.

**ADVANCED CONTROLS** – The fifth window highlighted after the OSD has been selected. It has four features: CORNER CORRECTION, VERTICAL LINEARTY, MOIRE, and ROTARY DEFAULT. To adjust these features, turn to page 12.

**SPECIAL CONTROLS** – The fourth window highlighted after the OSD has been selected. It has four features: LANGUAGE, OSD CONTROLS, VIDEO INPUT AND POWER SAVING. To adjust these features, turn to pages 10 - 11.

*Note: LANGUAGE allows you to change the On Screen Display from English to French, Spanish, German, or Italian. See page 10 for details.*







# HOW TO USE THE ON SCREEN DISPLAY (OSD)


## MAIN CONTROLS WINDOW


### BRIGHTNESS


 To adjust your screen's brightness, follow the steps below. Brightness is the overall intensity of the light coming from the screen. A 50% brightness level is recommended.




 Press the ON SCREEN DISPLAY button to return to MAIN CONTROLS window.


 Press the ON SCREEN DISPLAY button to bring up BRIGHTNESS screen.




 Turn the ROTARY knob (at the lower right-hand corner of the monitor) to adjust the brightness.


### CONTRAST


 To adjust your screen's contrast, follow the steps below. Contrast is the difference between the light and dark areas on the screen. A 100% contrast level is recommended.



 Press the ON SCREEN DISPLAY button to return to MAIN CONTROLS window.

 Press the ON SCREEN DISPLAY button to bring up CONTRAST screen.



 Turn the ROTARY knob to adjust the contrast.

### SMART HELP

After returning to MAIN CONTROLS ...

... to continue to CONTRAST, turn the ROTARY knob until CONTRAST icon is highlighted. Next, follow steps 3 - 5 under CONTRAST.

... to exit completely, press the OSD button and hold for 1.5 seconds. (See page 15 for other exit options.)

### SMART HELP


After returning to MAIN CONTROLS ...

... to continue to DEGAUSS, turn the ROTARY knob until DEGAUSS icon is highlighted. Next, follow steps 2-3 under DEGAUSS (on the next page).


... to exit completely, press the OSD button and hold for 1.5 seconds. (See page 15 for other exit options.)


# HOW TO USE THE ON SCREEN DISPLAY (OSD)

## MAIN CONTROLS WINDOW



### DEGAUSS



 To degauss your screen, follow the steps below. Degaussing removes electromagnetic build up that may distort the color on your screen.



Press the ON SCREEN DISPLAY button.

Press the ON SCREEN DISPLAY button. Next, turn the ROTARY knob until the DEGAUSS icon is highlighted.

For a moment, the screen will be distorted. Then it will return to normal. You will be back at the MAIN CONTROLS window.




Press the ON SCREEN DISPLAY button to degauss your screen.

### SMART HELP

**After returning to MAIN CONTROLS ...**

... to continue to the SCREEN SIZE & POSITION window, turn the ROTARY knob until EXIT is highlighted. Next, press the OSD button. Turn to the next page and follow steps 2 - 5 under FULL SIZE.


... to exit completely, press the OSD button and hold for 1.5 seconds. (See page 15 for other exit options.)




# HOW TO USE THE ON SCREEN DISPLAY (OSD)

## SCREEN SIZE & POSITION WINDOW


### FULL SIZE

 Full Size allows you to adjust the image on your screen to its maximum height and width. If nothing happens when you use this feature, the image is already at full size. You can use Full Size to both enable and disable this feature. *Note: Full Size only works with the monitor's factory presets.*




Press the ON SCREEN DISPLAY button.

Turn the ROTARY knob until the SCREEN SIZE & POSITION window is highlighted. Next, press the ON SCREEN DISPLAY button. The FULL SIZE icon is highlighted.





The image will automatically adjust to full size. You can now go on to your next adjustment.

Press the ON SCREEN DISPLAY button.



### HORIZONTAL POSITION


 Horizontal Position shifts the image on your screen either to the left or right. Use this feature if your image does not appear centered.




Press the ON SCREEN DISPLAY button.

Turn the ROTARY knob until the SCREEN SIZE & POSITION window is highlighted. Next, press the ON SCREEN DISPLAY button. Then, turn the ROTARY knob until HORIZONTAL POSITION is highlighted.

Press the ON SCREEN DISPLAY button to return to SCREEN SIZE & POSITION.



Press the ON SCREEN DISPLAY button to bring up HORIZONTAL POSITION screen.



Turn the ROTARY (at the lower right-hand corner of the monitor) knob until the image is horizontally balanced.

### SMART HELP

After returning to SCREEN SIZE & POSITION ...

... to continue to HORIZONTAL POSITION, turn the ROTARY knob until HORIZONTAL POSITION is highlighted. Next, follow steps 3 - 5 under HORIZONTAL POSITION.

... to exit completely, press the OSD button and hold for 1.5 seconds. (See page 15 for other exit options.)

### SMART HELP


After returning to SCREEN SIZE & POSITION ...

... to continue to HORIZONTAL SIZE, turn the ROTARY knob until HORIZONTAL SIZE is highlighted. Next, follow steps 3 - 5 under HORIZONTAL SIZE (on the next page).

... to exit completely, press the OSD button and hold for 1.5 seconds. (See page 15 for other exit options.)


# HOW TO USE THE ON SCREEN DISPLAY (OSD)

## SCREEN SIZE & POSITION WINDOW




### HORIZONTAL SIZE

Horizontal Size expands or contracts the image on your screen, pushing it out toward the left and right sides or pulling it in toward the center.




Press the On Screen Display button.



Turn the ROTARY knob until the SCREEN SIZE & POSITION window is highlighted. Next, press the On Screen Display button. Then, turn the ROTARY knob until HORIZONTAL SIZE is highlighted.



Press the On Screen Display button to return to SCREEN SIZE & POSITION.




Press the On Screen Display button to bring up HORIZONTAL SIZE screen.




Turn the ROTARY knob (at the lower right-hand corner of the monitor) until the image is the horizontal size you want.

### VERTICAL POSITION

Vertical Position adjusts the image on your screen either up or down. Use this feature if your image does not appear centered. Vertical Size expands or contracts the image on your screen, pushing it out toward the top and bottom sides or pulling it in toward the center.




Press the On Screen Display button.




Turn the ROTARY knob until the SCREEN SIZE & POSITION window is highlighted. Next, press the On Screen Display button. Then, turn the ROTARY knob until VERTICAL POSITION or VERTICAL SIZE is highlighted.



Press the On Screen Display button to return to SCREEN SIZE & POSITION.



Press the On Screen Display button to bring up VERTICAL POSITION or VERTICAL SIZE screen.



Turn the ROTARY knob until the image is vertically balanced or the vertical size your want.

### SMART HELP

#### After returning to SCREEN SIZE & POSITION ...

... to continue to VERTICAL POSITION, turn the ROTARY knob until VERTICAL POSITION is highlighted. Next, follow steps 3 - 5 under VERTICAL POSITION.


... to exit completely, press the OSD button and hold for 1.5 seconds. (See page 15 for other exit options.)

### SMART HELP

#### After returning to SCREEN SIZE & POSITION ...

... to continue to COLOR TEMPERATURE, turn the ROTARY knob until EXIT is highlighted. Next, press the OSD button. Then follow steps 2-4 under COLOR TEMPERATURE WINDOW on the next page.

... to exit completely, press the OSD button and hold for 1.5 seconds. (See page 15 for other exit options.)




# HOW TO USE THE ON SCREEN DISPLAY (OSD)



## COLOR TEMPERATURE WINDOW

**9300 K CAD/CAM / 6500 K DTP / 5500 K PHOTO RETOUCH**


**1** Your monitor has three preset options you can choose from. One **1** for Computer Aided Design (CAD) work. Two **2** for Desktop Publishing (DTP). And three **3** for Photo Retouch. When you select an option, the computer automatically adjusts itself for that selection.



Press the On Screen Display button.




Turn the Rotary knob until the COLOR TEMPERATURE window is highlighted. Then press the On Screen Display button.



Turn the Rotary knob until CAD/CAM, DTP, or PHOTO RETOUCH is highlighted.

After each preset setting is saved, the on screen display automatically returns to the COLOR TEMPERATURE window. To save the next preset setting, simply repeat the steps listed here.



Press the On Screen Display button to bring up and save the preset settings for 9300 K CAD/CAM, 6500 K DTP, or 5500 K PHOTO RETOUCH.

## SMART HELP


### After returning to COLOR TEMPERATURE ...

- ... to continue to USER PRESETS, turn the ROTARY knob until USER PRESETS is highlighted. Next, follow steps 3 - 9 under USER PRESETS on the next page.
- ... to exit completely, press the OSD button and hold for 1.5 seconds. (See page 15 for other exit options.)



# HOW TO USE THE ON SCREEN DISPLAY (OSD)


## COLOR TEMPERATURE WINDOW



### USER PRESETS




If you need to adjust any of the three preset options (CAD/CAM, DTP, or PHOTO RETOUCH), follow the steps below to modify the colors that appear on your screen. You can make individual adjustments to each of the preset options.



Press the On Screen Display button.




Turn the ROTARY knob until the COLOR window is highlighted. Next, press the On Screen Display button. Then, turn the ROTARY knob until USER PRESETS icon is highlighted.



Press the On Screen Display button to bring up the USER PRESETS window.



You will now be back at the USER PRESETS window. See SMART HELP below for options.




To exit User PRESET 1, press the On Screen Display button.



If necessary, turn the ROTARY knob until 1 of the User PRESETS is highlighted. Next, press the On Screen Display button.



When done with green, press the On Screen Display button. Turn rotary to BLUE, BLUE will be highlighted.



To adjust the blue, press the On Screen Display button again. Then, turn the ROTARY knob to increase or decrease the blue.



When done with red, press the On Screen Display button. Turn rotary to GREEN, GREEN will be highlighted. To adjust the green, press the On



Screen Display button again. Then, turn the ROTARY knob to increase or decrease the green.



First, press the On Screen Display button. RED will be highlighted. Next, to adjust the red, press the



On Screen Display button again. Then, turn the ROTARY knob to increase or decrease the red.

### SMART HELP

#### USER PRESETS

GO BACK

1 2


To exit User PRESETS (step 3 above), turn the ROTARY knob until the Go Back icon is highlighted. Go Back appears by the icon when highlighted. Next, press the On Screen Display button. You will be back at the COLOR TEMPERATURE window.

After returning to COLOR TEMPERATURE ...

... to continue to User PRESET 2 or 3, repeat steps 3 through 8, selecting either User PRESET 2 or User PRESET 3.

... to continue to SPECIAL CONTROLS window, turn the ROTARY knob until EXIT is highlighted. Next, press the On Screen Display button. Then, turn the ROTARY knob until SPECIAL CONTROLS is highlighted. Now, follow steps 2 - 5 under SPECIAL CONTROLS on the next page.

... to exit the On Screen Display completely, press the OSD button and hold for 1.5 seconds. (See page 15 for other exit options.)




# HOW TO USE THE ON SCREEN DISPLAY (OSD)


## SPECIAL CONTROLS WINDOW

### LANGUAGE

The On Screen Display shows its settings in one of five languages. The default is English, but you can select French, Spanish, German, or Italian.



Press the ON SCREEN DISPLAY button to confirm your selection and return to SPECIAL CONTROLS.




Press the On Screen Display button to bring up LANGUAGE screen.




Turn the Rotary knob (at the lower right-hand corner of the monitor) until desired language is selected.

### POWER SAVING


POWER SAVING helps save energy when the monitor is on but not being used. After a preset time, the monitor will go blank if not being used. To select POWER SAVING, follow the steps below.



Press the On Screen Display button to confirm your selection and return to SPECIAL CONTROLS.



Press the On Screen Display button to bring up POWER SAVING screen.



Turn the Rotary knob to select POWER SAVING ON or OFF.

### SMART HELP

#### After returning to SPECIAL CONTROLS ...

... to continue to POWER SAVING, turn the Rotary knob until POWER SAVING icon is highlighted. Next, follow steps 3 - 6 under POWER SAVING

... to exit completely, press the OSD button and hold for 1.5 seconds. (See page 15 for other exit options.)

### SMART HELP


#### After returning to SPECIAL CONTROLS ...

... to continue to OSD CONTROLS, turn the Rotary knob until OSD CONTROLS icon is highlighted. Next, follow steps 3 - 6 under OSD CONTROLS

... to exit completely, press the OSD button and hold for 1.5 seconds. (See page 15 for other exit options.)


# HOW TO USE THE ON SCREEN DISPLAY (OSD)

## SPECIAL CONTROLS WINDOW




### OSD CONTROLS

- WITH OSD CONTROLS, you can set the time for the On Screen Display to time out, and change the vertical and horizontal position of the OSD on the monitor screen.




Press the On Screen Display button.



Turn the ROTARY knob until SPECIAL CONTROLS is highlighted. Next, press the On Screen Display button. Then, turn the ROTARY knob until the OSD CONTROLS icon is highlighted.

Turn the ROTARY knob to select either VERTICAL or HORIZONTAL POSITION and repeat steps 3 - 6.



Press the On Screen Display button to add your change and return to OSD CONTROLS.



Press the On Screen Display button to bring up OSD CONTROLS screen.


Turn the ROTARY knob to select 05, 10, 25 seconds, or OFF.




Press the On Screen Display button to bring up TIMER screen.

### VIDEO INPUT

- VIDEO INPUT helps determine what you see on the screen. It is set at 0.7V(olts), but if the video input signal is different than the output signal, you may want to change it to 1.0V.




Press the On Screen Display button.



Turn the ROTARY knob until SPECIAL CONTROLS is highlighted. Next, press the On Screen Display button. Then, turn the ROTARY knob until the VIDEO INPUT icon is highlighted.

Press the On Screen Display button to save your selection and return to SPECIAL CONTROLS.



Press the On Screen Display button. The VIDEO INPUT screen appears.



Turn the ROTARY knob to select either 0.7V or 1.0V.

### SMART HELP

After returning to SPECIAL CONTROLS...

... to continue to VIDEO INPUT, turn the ROTARY knob until Go BACK is highlighted. Next, press the On Screen Display button. Then, turn the ROTARY knob until the VIDEO INPUT icon is highlighted. Next, follow steps 3 - 6 under VIDEO INPUT.


... to exit completely, press the OSD button and hold for 1.5 seconds. (See page 15 for other exit options.)



### SMART HELP

After returning to SPECIAL CONTROLS...

... to continue to ADVANCED CONTROLS, turn the ROTARY knob until EXIT is highlighted. Next, press the On Screen Display button. Then, turn the ROTARY knob to ADVANCED CONTROLS window and go to the next page. ... to exit completely, press the OSD button and hold for 1.5 seconds. (See page 15 for other exit options.)




# HOW TO USE THE ON SCREEN DISPLAY (OSD)

## ADVANCED CONTROLS WINDOW

### ROTARY DEFAULT

**ROTARY DEFAULT** allows you to pick the feature your ROTARY knob will default to when not used in adjusting your ON SCREEN DISPLAY. The normal default is brightness. To select your ROTARY DEFAULT, follow the steps below.




Press the ON SCREEN DISPLAY button.




Turn the ROTARY knob until **ADVANCED CONTROLS** is highlighted. Then, press the ON SCREEN DISPLAY button to highlight **ROTARY DEFAULT** icon.



Press the ON SCREEN DISPLAY button to add your adjustment and return to **ADVANCED CONTROLS**.



Press the ON SCREEN DISPLAY button to bring up **ROTARY DEFAULT** screen.



Turn the ROTARY knob to select **BRIGHTNESS, CONTRAST**

### SMART HELP


**After returning to ADVANCED CONTROLS ...**

... to continue to **MOIRE**, turn the ROTARY knob until **MOIRE** is highlighted. Next, follow steps 3 - 5 under **MOIRE**.


... to exit completely, press the OSD button and hold for 1.5 seconds. (See page 15 for other exit options.)

### MOIRE

**MOIRE** is a fringe pattern arising from the interference between two superimposed line patterns. To adjust your **MOIRE**, follow the steps below. *Note: Use only if necessary. By activating **MOIRE**, sharpness can be affected.*




Press the ON SCREEN DISPLAY button.



Turn the ROTARY knob until **ADVANCED CONTROLS** is highlighted. Next, press the ON SCREEN DISPLAY button. Then, turn the ROTARY knob until the **MOIRE** icon is highlighted.



Press the ON SCREEN DISPLAY button to add your adjustment and to bring up **ADVANCED CONTROLS** screen. See **SMART HELP** to select **VERTICAL MOIRE** or turn **MOIRE OFF**.



Press the ON SCREEN DISPLAY button to bring up **MOIRE** screen.



Turn the ROTARY knob to adjust the moire.



Turn the ROTARY knob until **HORIZONTAL MOIRE** is highlighted. Then, press the ON SCREEN DISPLAY button.

### SMART HELP

...to select **VERTICAL MOIRE** or to turn **MOIRE** off, follow the steps above, selecting **VERTICAL MOIRE** or **MOIRE OFF** in STEP 4.


**After returning to ADVANCED CONTROLS ...**

... to continue to **VERTICAL LINEARITY**, turn the ROTARY knob until **VERTICAL LINEARITY** icon is highlighted. Next, follow steps 4 - 5 under **VERTICAL LINEARITY** (on the next page).

... to exit completely, press the OSD button and hold for 1.5 seconds. (See page 15 for other exit options.)


# HOW TO USE THE ON SCREEN DISPLAY (OSD)

## ADVANCED CONTROLS WINDOW




### VERTICAL LINEARITY

Linearity is the degree with which the actual location of a pixel on the screen corresponds with its intended location. To adjust your VERTICAL LINEARITY, follow the steps below.




Press the On Screen Display button.




Turn the ROTARY knob until ADVANCED CONTROLS is highlighted. Next, press the On Screen Display button. Then, turn the ROTARY knob until the VERTICAL LINEARITY icon is highlighted.



Press the On Screen Display button to add your adjustment and to bring up ADVANCED CONTROLS screen.




Press the On Screen Display button to bring up VERTICAL LINEARITY screen.




Turn the ROTARY knob to adjust the vertical linearity.

### CORNER CORRECTION

CORNER CORRECTION "squares up" the corners of an image on the screen. To adjust your CORNER CORRECTION, follow the steps below.




Press the On Screen Display button.



Turn the ROTARY knob until ADVANCED CONTROLS is highlighted. Next, press the On Screen Display button. Then, turn the ROTARY knob until the CORNER CORRECTION icon is highlighted.



Press the On Screen Display button to bring up ADVANCED CONTROLS screen.



Press the On Screen Display button to bring up CORNER CORRECTION screen.



Turn the ROTARY knob until desired corner correction is selected.

### SMART HELP

#### After returning to ADVANCED CONTROLS ...

... to continue to CORNER CORRECTION, turn the ROTARY knob until CORNER CORRECTION icon is highlighted. Next, follow steps 3 - 4 under CORNER CORRECTION.


... to exit completely, press the OSD button and hold for 1.5 seconds. (See page 15 for other exit options.)

### SMART HELP

#### After returning to ADVANCED CONTROLS ...

... to continue to GEOMETRY WINDOW, turn the ROTARY knob until EXIT is highlighted. Next, press the OSD button. Then follow steps 2a - 2c under GEOMETRY WINDOW on the next page.

... to exit completely, press the OSD button and hold for 1.5 seconds. (See page 15 for other exit options.)




# HOW TO USE THE ON SCREEN DISPLAY (OSD)

## GEOMETRY CONTROLS WINDOW

### PINCUSHION, BALANCED PINCUSHION, TRAPEZOID, PARALLELOGRAM, ROTATION




Follow the steps below to adjust any of the five preset options (PINCUSHION, BALANCED PINCUSHION, TRAPEZOID, PARALLELOGRAM, or ROTATION). You can make individual adjustments to each of the preset options. *Note: use these features only when the picture is not square.*



Press the On Screen Display button.

Turn the ROTARY knob until the GEOMETRY CONTROLS window is highlighted. Next, press the On Screen Display button. Then, if necessary, turn the ROTARY knob until PINCUSHION icon is highlighted.




Press the On Screen Display button. Then, turn the ROTARY knob to adjust the pincushion.



When done, press the On Screen Display button to save the change and return to GEOMETRY CONTROLS window.

To select PARALLELOGRAM or ROTATION, turn the ROTARY knob until PARALLELOGRAM or ROTATION icon is highlighted. Next, press the On Screen Display button. Then follow steps 4b and 4c to make the appropriate changes.



When done, press the On Screen Display button. This will save the change and return the screen to GEOMETRY CONTROLS window.




Turn the ROTARY knob to adjust the trapezoid.

To select TRAPEZOID, turn the ROTARY knob until TRAPEZOID icon is highlighted. Next, press the On Screen Display button.



When done, press the On Screen Display button. This will save the change and return the screen to GEOMETRY CONTROLS.



Turn the ROTARY knob (on the lower right-hand corner of the monitor) to adjust the balanced pincushion.

## SMART HELP

### To exit GEOMETRY CONTROLS ...


... but continue to another window, turn the ROTARY knob until Exit is highlighted. Next, press the On Screen Display button. Then, turn the ROTARY knob until that window is highlighted. Now, press the On Screen Display button and follow the instructions for that window.

... completely, press the On Screen Display button and hold for 1.5 seconds. The On Screen Display will disappear. All changes will be saved.

To make changes to one item, follow the steps for that item. Then, follow "To exit GEOMETRY CONTROLS ..."

To return to factory presets, see "To Reset an Individual Window" on page 15.

# HOW TO USE THE ON SCREEN DISPLAY (OSD)




## EXIT AND RESET


### EXIT & RESET FROM A WINDOW

Choosing EXIT allows you to go to another window. Choosing RESET returns all the settings in that window to factory presets.


#### TO EXIT AN INDIVIDUAL WINDOW



Make sure you are at a window. For example, MAIN CONTROLS. An icon will be highlighted. For example, BRIGHTNESS.




Turn the ROTARY knob until EXIT is highlighted. Next, press the ON SCREEN DISPLAY button.




An entire window is now highlighted. Turn the ROTARY knob to another window and begin adjustments, or turn the knob until EXIT is highlighted as shown in EXIT FROM OSD (at right).


#### TO RESET AN INDIVIDUAL WINDOW



Make sure you are at a window. For example, MAIN CONTROLS. An icon will be highlighted. For example, BRIGHTNESS.



Turn the ROTARY knob until RESET is highlighted. Next, press the ON SCREEN DISPLAY button.




The first icon in the reset window is now highlighted. Turn the ROTARY knob to select another icon and begin adjustments, or turn the knob until EXIT is highlighted as shown above.


### EXIT & RESET FROM THE ON SCREEN DISPLAY

Exiting from the On Screen Display removes the On Screen Display from the monitor screen. Resetting from the On Screen Display returns everything in all the windows to factory presets.

#### TO EXIT AN ENTIRE ON SCREEN DISPLAY




Make sure you have exited from all icons in a window. (See TO EXIT FROM AN INDIVIDUAL WINDOW.) For example, MAIN CONTROLS will be highlighted.




Turn the ROTARY knob until EXIT is highlighted. Next, press the ON SCREEN DISPLAY button. The On Screen Display will disappear.


#### RESET ENTIRE ON SCREEN DISPLAY




Make sure you have exited from all icons in a window. (See TO EXIT FROM AN INDIVIDUAL WINDOW.) For example, MAIN CONTROLS will be highlighted.



Turn the ROTARY knob until RESET is highlighted. Next, press the ON SCREEN DISPLAY button.




Turn the ROTARY knob to select No or Yes. Then press the ON SCREEN DISPLAY button.



If No is selected the On Screen Display appears and MAIN CONTROLS is highlighted.

If Yes is selected the EXIT OSD screen appears.





## ADDITIONAL HOOK UP OPTIONS

### BNC AND USB SET UPS

#### BNC CONNECTIONS

BNC is another way to connect the monitor to the computer. This connection requires an optional BNC cable. It can be connected to either a Macintosh- or IBM-compatible computer. For those who work with graphics or designs, this option may be better.

**Note:** Be sure to flip the D-Sub/BNC switch to BNC when using this connection.


##### For an IBM-compatible computer:

1. Turn off the computer.
2. Connect the (optional) BNC monitor cable and set D-Sub/BNC switch to BNC.
3. Connect the shielded power cable.
4. Turn on the monitor. Then turn on the computer.
5. If you have Windows '95, follow the "If you have Windows '95" steps on the Setting Up foldout sheet.

##### For a Macintosh-type computer:

1. Connect the Mac adapter to one end of the monitor cable.
2. Turn off the computer.
3. Connect the (optional) BNC monitor cable and set D-Sub/BNC switch to BNC.
4. Connect the shielded power cable.
5. Turn on the monitor. Then turn on the computer.

D-Sub/BNC Switch



Refer to the "Setting Up your Philips monitor" foldout for a more detailed guide to setting up your monitor.


#### USB CONNECTIONS

USB (Universal Serial Bus) is an innovation in connecting your IBM-compatible computer to your monitor. By using the USB, you will be able to connect your keyboard, mouse, printer, and other peripherals to your monitor instead of having to connect them to your computer. This will give you greater flexibility in setting up your system. Plus, you will have true plug-and-play capability. While the software is still being developed, Philips has included the hardware so you will be ready to take advantage of this next generation in computer development.

##### For an IBM-compatible Computer:

1. Turn off the computer.
2. Connect the (optional) USB Hub and cable to the computer and to the monitor. (Computer must have USB port.)
3. Connect the shielded power cable.
4. Turn on the monitor. Then turn on the computer.
5. With the installation of the correct software, you will be able to connect specially-made peripherals to the monitor.


**Note:** USB Hub and cables sold separately. USB Bay exists in back of monitor.



Refer to the "Setting Up your Philips monitor" foldout for a more detailed guide to setting up your monitor.

## ADDITIONAL INFORMATION

### POWER SAVING FEATURE



### AUTOMATIC POWER SAVINGS & PRESET RESOLUTION MODES

If you have VESA's DPMS compliance display card or software installed in your PC, the monitor can automatically reduce its power consumption when not in use. If input from a keyboard, mouse, or other device is detected, the monitor automatically "wakes up." The table directly below shows the power consumption and signalling of this automatic power-saving feature. To turn this feature on and off, see page 10. The tables at the bottom of the page show the 13/14 factory preset resolution modes. This leaves room for additions.



Power Management Definition

VESA's mode	Video	H-sync	V-sync	Power used	Power saving(%)	LED color
ON	Active	Yes	Yes	< 160W	0%	Green
Stand-by	Blanked	No	Yes	< 15W	87.5%	Yellow
Suspend	Blanked	Yes	No	< 15W	87.5%	Yellow
OFF	Blanked	No	No	< 5W	95.8%	Amber

This monitor is Energy Star compliant and power management compatible.

AS AN ENERGY STAR PARTNER, PHILIPS HAS DETERMINED THAT THIS PRODUCT MEETS THE ENERGY STAR GUIDELINES FOR ENERGY EFFICIENCY.

The proper operation of the function requires a computer with VESA DPMS power management capabilities. When used with a computer equipped with VESA DPMS, the monitor is Energy Star compliant.


### 201B

Factory Preset Resolution Modes				
MODE	RESOLUTION	H. FREQ. (KHz)	V. FREQ. (Hz)	STANDARD
1	640 x 400	31.5	70	VGA
2	640 x 480	31.5	60	VGA
3	640 x 480	37.5	75	VESA/75
4	800 x 600	46.9	75	VESA/75
5	800 x 600	53.7	85	VESA/85
6	1024 x 768	60	75	VESA/75
7	1024 x 768	68.7	85	VESA/85
8	1152 x 870	69.0	75	MAC
9	1152 x 900	71.8	76	SUN SPARC
10	1280 x 1024	80.0	75	VESA/75
11	1280 x 1024	91.1	85	VESA/85
12	1600 x 1200	106.3	85	VESA/85
13	1800 x 1350	105.5	75	

### 201P

Factory Preset Resolution Modes				
MODE	RESOLUTION	H. FREQ. (KHz)	V. FREQ. (Hz)	STANDARD
1	640 x 400	31.5	70	VGA
2	640 x 480	31.5	60	VGA
3	640 x 480	37.5	75	VESA/75
4	800 x 600	46.9	75	VESA/75
5	800 x 600	53.7	85	VESA/85
6	1024 x 768	60	75	VESA/75
7	1024 x 768	68.7	85	VESA/85
8	1152 x 870	69.0	75	MAC
9	1152 x 900	71.8	76	SUN SPARC
10	1280 x 1024	80.0	75	VESA/75
11	1280 x 1024	91.1	85	VESA/85
12	1600 x 1200	106.3	85	VESA/85
13	1800 x 1350	105.5	75	
14	1600 x 1200	112.5	90	

Unit is capable of up to 1800 x 1440 with user definable modes. 201P/201B Monitors are compliant with EISA standard timing requirements.




## ADDITIONAL INFORMATION

COMING TO TERMS WITH THIS BOOK

### PIN ASSIGNMENT

The 15-pin D-sub connector (male) of the signal cable:

Pin No.	Assignment
1	Red video input
2	Green video input
3	Blue video input
4	Identical output - connected to pin 10
5	Self test
6	Red video ground
7	Green video ground
8	Blue video ground
9	No pin
10	Logic ground
11	Identical output - connected to pin 10
12	Serial data line (SDA)
13	H. Sync / H+V
14	V. Sync (VCLK for DDC)
15	Data clock line (SCL)



### SPECIFICATIONS

#### GENERAL

##### CRT

Screen size	:21" (53.3 cm) flat & square
Viewable Image Size (VIS)	:19.9"
Focusing method	:Dynamic focus
Dot pitch	:0.22 mm (horizontal)
Phosphor	:P22 or equivalent, medium short persistence
Screen treatment	:ARASC

##### Display area

Factory preset	:380 mm (H) x 285 mm (V)
Maximum usable	:406 mm (H) x 304 mm (V)

##### Scanning frequency

Horizontal (line)	:30-115kHz(201P) (AutoScan) 30-107kHz(201B) (AutoScan)
Vertical (frame)	:50-160 Hz (AutoScan)

##### Input power

	:100-240 V AC, 50-60 Hz
--	-------------------------

##### Power consumption

	:110 Watt normal, 160 Watt max.
	:(201B) 375.4 BTU normal, 511.9 BTU maximum
	:(201P) 375.4 BTU normal, 546.1 BTU maximum

##### Input signal

Video	:0.7 or 1.0 Vpp, 75 Ohm impedance
Sync	:Separate sync. TTL level Composite sync. TTL level

##### Pedestal

Tilt	:5° forward, 11° backward
Swivel	:90° left, 90° right

##### Physical

Unit dimension (WxHxD)	:490 x 529 x 551 mm 19.3" x 21.7" x 20.8"
Net weight	:31.5 kg 69.3 lbs.

##### Operating conditions

Temperature	:0° C - 40° C 32° F - 104° F
Humidity	:10% - 90%

##### Storage conditions

Temperature	:-40° C - 60° C -20° F - 140° F
Humidity	:5% - 95%

### INDEX

Automatic Power Saving	17	Power button	Set Up Guide, 2
Balanced Pincushion	14	Power plug	Set Up Guide, 2
BNC jacks	2	Power Saving	11
BNC set up	16	Reset	15
Brightness	4	Resolution Modes	17
Cable Cover	2	Rotary Default	12
CAD/CAM	8, 9	Rotary knob	2
Color Temperature	3, 8-9	Rotation	14
Contrast	4	Safety precautions	1
Corner Correction	13	Screen Size & Position	3, 6-7
Degauss	5	Special Controls	3, 10-11
Description of controls	2, 3	Specifications	18
D-Sub/BNC switch	2, 16	Trapezoid	14
DTP	8, 9	Troubleshooting	19, Set Up Guide
End-of-life disposal	1	USB hub	2, 16
Exit	15	USB set up	16
Features	1	User Presets	9
Full Size	6	Vertical Linearity	13
Geometry Controls	3, 14	Vertical Position	7
Glossary	18	Vertical Size	7
Hook Ups	Set Up Guide, 16	Video Input	11
Horizontal Position	6	Warranty (Appendix)	120
Horizontal Size	7		
Language	10		
Main Controls	3, 4-5		
Maintenance	1		
Moire	12		
Monitor cable plug	2		
On Screen Display	2		
OSD button	2		
OSD Controls	10		
Parallelogram	14		
Pedestal	2		
Photo Retouch	8, 9		
Pin Assignment	18		
Pincushion	14		


### GLOSSARY

Here are a few definitions that may help you.

Degauss	The process by which metal parts of the monitor are demagnetized in order to reduce screen distortion and color impurity.
D-Sub/BNC	Two ways of connecting your monitor to your computer. Your monitor comes with a D-Sub cable. For work with a heavy emphasis on graphics, a BNC cable is recommended.
Geometry	A set of controls that allows you to adjust the alignment of the picture on the monitor screen. The goal is to "square up" the picture. This is done by adjusting such items as balanced pincushion, pincushion, parallelogram, rotation, and trapezoid.
Moire	A fringe pattern caused by the interference between two superimposed line patterns.
USB	Universal Serial Bus. A way to connect your computer, monitor, and peripherals for true Plug-and-Play functions.

## ADDITIONAL INFORMATION

### WHAT TO DO IF SOMETHING ISN'T WORKING



#### TROUBLESHOOTING

Having trouble? Something not working? Before calling for help, try these suggestions.

##### HAVING THIS PROBLEM?

No Picture

(Power LED not lit)

##### CHECK THESE ITEMS

Make sure the Power cable is plugged in the wall and back of the monitor.

Power button on top of the monitor should be in the ON position.

Disconnect the monitor from the power outlet for about one minute.

No Picture

(Power LED is Amber  
or Yellow in color)

Make sure the computer is turned on.

Make sure the D-Sub/BNC switch on the rear of the monitor is in the correct position. See pages 2 and 16.

Make sure the monitor cable is properly connected to your computer.

Check to see if the monitor cable has bent pins.

The Energy Saving Feature may be activated. See pages 12 and 17 for more detail.

No Picture

(Power LED is Green  
in color)

Make the Brightness and Contrast controls are set correctly. See page 4 for details

Make sure the D-Sub/BNC switch on the rear of the monitor is in the correct position. See pages 2 and 16.

Make sure the monitor cable is properly connected to your computer.

Check to see if the monitor cable has bent pins.

Make sure the computer Power button is on.

Screen says



Make sure the D-Sub/BNC switch on the rear of the monitor is in the correct position. See pages 2 and 16.

Make sure the monitor cable is properly connected to your computer. See Setting Up foldout.

Check to see if the monitor cable has bent pins.

Make sure the computer is turned on

when you turn on  
the monitor.

No Color

If you are using a non-VESA-DDC standard video card, consult your local Philips dealer or service organization to obtain an adapter.

Color appears blotchy

The picture may need degaussing. See page 5 for details.

Remove any nearby magnetic objects.

Face the monitor East for best picture quality.

Missing one or  
more colors

Check user settings of Color Temperature. See pages 8 and 9 for details.

Make sure the monitor cable is properly connected to your computer.

Check to see if the monitor cable has bent pins.

Dim Picture

Adjust the Brightness and Contrast controls. See page 4 for details.

Check the Video Input selection and switch from 0.7 volts to 1.0 volts or 1.0 volts to 0.7 volts. See page 11.

Check your video card and the manual instructions for it. It may be a non-VESA-DDC Standard card.

Picture is too large  
or too small

Adjust the Horizontal and/or Vertical Size. See pages 7 and 8 for details.

Edges of the picture  
are not square

The geometry controls require adjusting. See page 14 for details.

Picture has a double  
image

Eliminate the use of a video extension cable and/or video switch box.

Face the monitor East for best picture quality.

Picture is not sharp

Check to make sure Moire is switched off. See page 12.

Unstable Picture

Increase your refresh rate. Consult your computer manual for details.

Windows '95 cannot  
find your video card

Select "Super VGA" under STANDARD DISPLAY TYPES, or contact your video card manufacturer for the right drivers.

# TELEVISION/MONITOR SAFETY GUIDELINES FOR THE PROFESSIONAL SERVICE TECHNICIAN

## Safety Checks

After the original service problem has been corrected, a complete safety check should be made. Be sure to check over the entire set, not just the areas where you have worked. Some previous servicer may have left an unsafe condition, which could be unknowingly passed on to your customer. Be sure to check all of the following:

## Fire and Shock Hazard

1. Be sure all components are positioned in such a way as to avoid the possibility of adjacent component shorts. This is especially important on those chassis which are transported to and from the service shop.
2. Never release a repaired unit unless all protective devices such as insulators, barriers, covers, strain reliefs, and other hardware have been installed in accordance with the original design.
3. Soldering and wiring must be inspected to locate possible cold solder joints, solder splashes, sharp solder points, frayed leads, pinched leads, or damaged insulation (including the ac cord). Be certain to remove loose solder balls and all other loose foreign particles.
4. Check across-the-line components and other components for physical evidence of damage or deterioration and replace if necessary. Follow original layout, lead length, and dress.
5. No lead or component should touch a receiving tube or a resistor rated at 1 watt or more. Lead tension around protruding metal surfaces or edges must be avoided.
6. Critical components having special safety characteristics are identified with an s by the Ref. No. in the parts list and enclosed within a broken line\* (where several critical components are grouped in one area) along with the safety symbols on the schematic diagrams and/or exploded views.
7. When servicing any unit, always use a separate isolation transformer for the chassis. Failure to use a separate isolation transformer may expose you to possible shock hazard, and may cause damage to servicing instruments.
8. Many electronic products use a polarized ac line cord (one wide pin on the plug). Defeating this safety feature may create a potential hazard to the servicer and the user. Extension cords which do not incorporate the polarizing feature should never be used.
9. After reassembly of the unit, always perform an ac leakage test or resistance test from the line cord to all exposed metal parts of the cabinet. Also, check all metal control shafts (with knobs removed), antenna terminals, handles, screws, etc. to be sure the unit may be safely operated without danger of electrical shock.

\* Broken line

## Implosion

1. All picture tubes used in current model receivers are equipped with an integral implosion system. Care should always be used, and safety glasses worn, whenever handling any picture tube. Avoid scratching or otherwise damaging the picture tube during installation.
2. Use only replacement tubes specified by the manufacturer.


## X-radiation

1. Be sure procedures and instructions to all your service personnel cover the subject of X-radiation. Potential sources of X-rays in TV receivers are the picture tube and the high voltage circuits. The basic precaution which must be exercised is to keep the high voltage at the factory recommended level.
2. To avoid possible exposure to X-radiation and electrical shock, only the manufacturer's specified anode connectors must be used.
3. It is essential that the service technician has an accurate HV meter available at all times. The calibration of this meter should be checked periodically against a reference standard.
4. When the HV circuitry is operating properly there is no possibility of an X-radiation problem. High voltage should always be kept at the manufacturer's rated value - no higher - for optimum performance. Every time a color set is serviced, the brightness should be run up and down while monitoring the HV with a meter to be certain that the HV is regulated correctly and does not exceed the specified value. We suggest that you and your technicians review test procedures so that HV and HV regulation are always checked as a standard servicing procedure, and the reason for this prudent routine is clearly understood by everyone. It is important to use an accurate and reliable HV meter. It is recommended that the HV reading be recorded on each customer's invoice, which will demonstrate a proper concern for the customer's safety.
5. When troubleshooting and making test measurements in a receiver with a problem of excessive high voltage, reduce the line voltage by means of a Variac to bring the HV into acceptable limits while troubleshooting. Do not operate the chassis longer than necessary to locate the cause of the excessive HV.

6. New picture tubes are specifically designed to withstand higher operating voltages without creating undesirable X-radiation. It is strongly recommended that any shop test fixture which is to be used with the new higher voltage chassis be equipped with one of the new type tubes designed for this service. Addition of a permanently connected HV meter to the shop test fixture is advisable. The CRT types used in these new sets should never be replaced with any other types, as this may result in excessive X-radiation.
7. It is essential to use the specified picture tube to avoid a possible X-radiation problem.
8. Most TV receivers contain some type of emergency "Hold Down" circuit to prevent HV from rising to excessive levels in the presence of a failure mode. These various circuits should be understood by all technicians servicing them, especially since many hold down circuits are inoperative as long as the receiver performs normally.

## Leakage Current Cold Check

1. Unplug the ac line cord and connect a jumper between the two prongs of the plug.
2. Turn on the power switch.
3. Measure the resistance value between the jumpered ac plug and all exposed cabinet parts of the receiver, such as screw heads, antennas, and control shafts. When the exposed metallic part has a return path to the chassis, the reading should be between 1 megohm and 5.2 megohms. When the exposed metal does not have a return path to the chassis, the reading must be infinity. Remove the jumper from the ac line cord.



## Leakage Current Hot Check

1. Do not use an isolation transformer for this test. Plug the completely reassembled receiver directly into the ac outlet.
2. Connect a 1.5k, 10W resistor paralleled by a 0.15µF capacitor between each exposed metallic cabinet part and a good earth ground such as a water pipe, as shown above.
3. Use an ac voltmeter with at least 5000 ohms/ volt sensitivity to measure the potential across the resistor.
4. The potential at any point should not exceed 0.75 volts. A leakage current tester may be used to make this test; leakage current must not exceed 0.5milliamps. If a measurement is outside of the specified limits, there is a possibility of shock hazard. The receiver should be repaired and rechecked before returning it to the customer.
5. Repeat the above procedure with the ac plug reversed. (Note: An ac adapter is necessary when a polarized plug is used. Do not defeat the polarizing feature of the plug.)

## Picture Tube Replacement

The primary source of X-radiation in this television receiver is the picture tube. The picture tube utilized in this chassis is specially constructed to limit X-radiation emissions. For continued X-radiation protection, the replacement tube must be the same type as the original, including suffix letter, or a Philips approved type.

## Parts Replacement

Many electrical and mechanical parts in Philips television sets have special safety related characteristics. These characteristics are often not evident from visual inspection nor can the protection afforded by them necessarily be obtained by using replacement components rated for higher voltage, wattage, etc. The use of a substitute part which does not have the same safety characteristics as the Philips recommended replacement part shown in this service manual may create shock, fire, or other hazards.

**WARNING:** Before removing the CRT anode cap, turn the unit **OFF** and short the **HIGH VOLTAGE** to the CRT **DAG** ground.  
**SERVICE NOTE:** The CRT **DAG** is not at chassis ground.